






PHYSIOLOGY LAB-6
MAY,2022

ASST. LEC. ZAKARIYA A. MAHDI

#### **HEMOSTASIS**

- DEFINITION
  - Heme = blood
  - stasis = to stop
- It is the process of forming clots in the wall of damaged blood vessels & preventing blood loss while maintaining blood in a fluid state with in the vascular system.
- P Defects in hemostasis can lead to an increased risk of bleeding (hemorrhage) or clotting (thrombosis).



#### **Events in Hemostasis**

#### ■ Vascular Constriction

-Damaged blood vessels constrict

#### Formation of platelet Plug

- Platelets adhere to damaged endothelium to form platelet plug (primary hemostasis).


#### **➡** Blood Coagulation

- Clots form upon the conversion of fibrinogen to Fibrin, and its addition to the platelet plug (secondary hemostasis).

# 2- STAGES OF PRIMARY HEMOSTASIS


- Platelet Adhesion
- **■** Platelet Activation
- **■** Platelet Aggregation

### platelet adhesion






# Platelet activation: platelet release action



Platelet release reaction

## Platelet aggregation



**3** Platelet aggregation


## 3- Secondary hemostasis

If there is a large hole in the blood vessel, a blood clot is additionally required.

## Cascade of reactions

It states that 'inactive' enzymes are activated, and the 'activated' enzymes in turn activates other inactive enzymes until final step is reached.

#### THE CLOTTING MECHANISM



#### 4-FIBRINOLYTIC PHASE

► The fibrinolytic system does not allow the fibrin clot to grow and block a vessel, which would cause serious complications. The dissolution of a clot, called fibrinolysis (dissolving of fibrin fibers), is brought about by the formation of the active enzyme plasmin from plasminogen

#### **HEMOSTASIS**

#### DEPENDENT UPON:

- Vessel Wall Integrity
- Adequate Numbers of Platelets
- Proper Functioning Platelets
- Adequate Levels of Clotting Factors
- Proper Function of Fibrinolytic Pathway

## So What Causes Bleeding Disorders?

**DVESSEL DEFECTS** 

OPLATELET DISORDERS

**DFACTOR DEFICIENCIES** 

## METHOD OF STUDY

#### **→** HEMOSTATIC FUNCTION TESTS

- -Bleeding time
- -Clotting time
- -Prothrombin time
- -Partial prothrombin time
- -Thrombin time

#### Note

The BT and CT are two simple tests that are used as a routine before every minor and major surgery (e.g. tooth extraction), biopsy procedures, and before and during anticoagulant therapy, whether or not there is a history of bleeding.

## 1-BLEEDING TIME (B.T)

#### Definition:

is the time interval between the skin puncture and spontaneous, unassisted (i.e. without pressure) stoppage of bleeding. The BT test is an *in vitro* test of <u>platelet function</u>.

Purpose: to detect qualitative defects of platelets.

Normal bleeding time ; 1 - 5 min.



## Bleeding Time

#### Medical applications:

The prolongation of bleeding time may be due to:

- 1. Defects in the blood vessels
- 2. /Decrease number of platelets(thromocytopenia)
- 3/. Defect in the function of the platelets caused by:
  - drugs (aspirin, NSAIDs, Anti coagulants, Sulfonamides, Diuretics, etc.)
- Inherited diseases (VON WILLEBRAND'S DISEASE.

## **Bleeding Time**

### Materials and methods

- Lancet
- Stop watch
- Circular filter paper
- Alcohol

## **Bleeding Time**

### Materials and methods

- A disposable lancet is used to make cut into the finger usually.
- A stopwatch is started immediately and every 30 seconds filter paper is used to draw off the blood.
- The time from when the incision is made until all bleeding has stopped is called the bleeding time.
- The test is finished when bleeding has stopped completely.
- Count the number of blood spots and express your result in minutes and seconds.

#### 2-PROTHROMBIN TIME

Measures Effectiveness of the Extrinsic Pathway.

Normal ratio 0.9-1.2



#### 3- PARTIAL THROMBOPLASTIN TIME

Measures Effectiveness of the IntrinsicPathway and common pathway

NORMAL VALUE 25-35 SECS



## 4-Thrombin Time (TT)

 Time to clot formation after addition of thrombin to citrated blood

Normal value : less than 15 seconds



#### 5-CLOTTING TIME ( C.T )

#### (COAGULATION TIME)

Definition:

is the time interval between the entry of blood into the glass capillary tube, or a syringe, and formation of fibrin threads

- Normal Clotting Time : 3 − 6 min.
- Prolonged clotting time is due to severe deficiency of any of the coagulation proteins.
- Weak friable clot called hypofibrinogenaemia.
- Method: capillary tube method.

## Clotting time - capillary method

#### Material

- 1. Sterile disposable pricking lancet.
- 2./ Stop watch
- Dry capillary tube (non heparinized)
- 4. Cotton Swab.
- 5. 70% ethyl alcohol

# Clotting time - capillary method

- Clean your finger with alcohol
- Prick the finger by a lancet and note the time using a stop watch
- Løad a capillary tube to at least ½ full
- After about 2 mins, take the loaded capillary tube between your thumb and forefingers and gently break in half
- Slowly pull the ends part to see the insoluble fibrin strands
- Do a break every 30 sec, once the clot is formed we record the time

The clotting of blood with this method involves both the <u>intrinsic</u> and the <u>extrinsic</u> systems of clotting. There is injury to the blood (coming in contact with glass, intrinsic pathway), and the injury to the tissues (extrinsic pathway).

## The coagulation time is increased in the following conditions:

- 1. Hemophilias
- 2. von Willebrand disease.
- 3. Afibrinogenemia and dysfibrinogenemia
- 4. Vitamin K deficiency

it acts a cofactor in the synthesis of prothrombin, and factors VII, IX and X

- 5. Liver diseases
- 6. Anticoagulant therapy. Patients receiving heparin or warfarin show an increased CT.
- 7.Newborns. Newborns, especially premature babies sometimes have a tendency to bleed because the plasma levels of certain factors are low

# WHY BLOOD DOES NOT CLOT IN CIRCULATION?

## Thank you