



CHAPTER

7

Natural Convection Systems

7-1 | INTRODUCTION

Our previous discussions of convection heat transfer have considered only the calculation of forced-convection systems where the fluid is forced by or through the heat-transfer surface. Natural, or free, convection is observed as a result of the motion of the fluid due to density changes arising from the heating process. A hot radiator used for heating a room is one example of a practical device that transfers heat by free convection. The movement of the fluid in free convection, whether it is a gas or a liquid, results from the buoyancy forces imposed on the fluid when its density in the proximity of the heat-transfer surface is decreased as a result of the heating process. The buoyancy forces would not be present if the fluid were not acted upon by some external force field such as gravity, although gravity is not the only type of force field that can produce the free-convection currents; a fluid enclosed in a rotating machine is acted upon by a centrifugal force field, and thus could experience free-convection currents if one or more of the surfaces in contact with the fluid were heated. The buoyancy forces that give rise to the free-convection currents are called *body forces*.

7-2 | FREE-CONVECTION HEAT TRANSFER ON A VERTICAL FLAT PLATE

Consider the vertical flat plate shown in Figure 7-1. When the plate is heated, a free-convection boundary layer is formed, as shown. The velocity profile in this boundary layer is quite unlike the velocity profile in a forced-convection boundary layer. At the wall the velocity is zero because of the no-slip condition; it increases to some maximum value and then decreases to zero at the edge of the boundary layer since the "free-stream" conditions are at rest in the free-convection system. The initial boundary-layer development is laminar; but at some distance from the leading edge, depending on the fluid properties and the temperature difference between wall and environment, turbulent eddies are formed, and transition to a turbulent boundary layer begins. Farther up the plate the boundary layer may become fully turbulent.

To analyze the heat-transfer problem, we must first obtain the differential equation of motion for the boundary layer. For this purpose we choose the *x* coordinate along the plate and the *y* coordinate perpendicular to the plate as in the analyses of Chapter 5. The only new force that must be considered in the derivation is the weight of the element of fluid.





7-2 Free-Convection Heat Transfer on a Vertical Flat Plate

Figure 7-1 | Boundary layer on a vertical flat plate.

Turbulent Turbulent Turbulent

As before, we equate the sum of the external forces in the x direction to the change in momentum flux through the control volume dx dy. There results

$$\rho\left(u\frac{\partial u}{\partial x} + v\frac{\partial u}{\partial y}\right) = -\frac{\partial p}{\partial x} - \rho g + \mu \frac{\partial^2 u}{\partial y^2}$$
 [7-1]

where the term $-\rho g$ represents the weight force exerted on the element. The pressure gradient in the x direction results from the change in elevation up the plate. Thus

$$\frac{\partial p}{\partial x} = -\rho_{\infty} g \tag{7-2}$$

In other words, the change in pressure over a height dx is equal to the weight per unit area of the fluid element. Substituting Equation (7-2) into Equation (7-1) gives

$$\rho\left(u\frac{\partial u}{\partial x} + v\frac{\partial u}{\partial y}\right) = g(\rho_{\infty} - \rho) + \mu\frac{\partial^2 u}{\partial y^2}$$
[7-3]

The density difference $\rho_{\infty} - \rho$ may be expressed in terms of the volume coefficient of expansion β , defined by

$$\beta = \frac{1}{V} \left(\frac{\partial V}{\partial T} \right)_p = \frac{1}{V_{\infty}} \frac{V - V_{\infty}}{T - T_{\infty}} = \frac{\rho_{\infty} - \rho}{\rho (T - T_{\infty})}$$

so that

$$\rho\left(u\frac{\partial u}{\partial x} + v\frac{\partial u}{\partial y}\right) = g\rho\beta(T - T_{\infty}) + \mu\frac{\partial^{2} u}{\partial y^{2}}$$
[7-4]

This is the equation of motion for the free-convection boundary layer. Notice that the solution for the velocity profile demands a knowledge of the temperature distribution. The energy equation for the free-convection system is the same as that for a forced-convection system at low velocity:

$$\rho c_p \left(u \frac{\partial T}{\partial x} + v \frac{\partial T}{\partial y} \right) = k \frac{\partial^2 T}{\partial y^2}$$
 [7-5]

The volume coefficient of expansion β may be determined from tables of properties for the specific fluid. For ideal gases it may be calculated from (see Problem 7-3)

$$\beta = \frac{1}{T}$$

where T is the absolute temperature of the gas.

Even though the fluid motion is the result of density variations, these variations are quite small, and a satisfactory solution to the problem may be obtained by assuming incompressible flow, that is, $\rho =$ constant. To effect a solution of the equation of motion, we use the integral method of analysis similar to that used in the forced-convection problem of Chapter 5. Detailed boundary-layer analyses have been presented in References 13, 27, and 32.

For the free-convection system, the integral momentum equation becomes

$$\frac{d}{dx} \left(\int_0^\delta \rho u^2 \, dy \right) = -\tau_w + \int_0^\delta \rho g \beta (T - T_\infty) \, dy$$

$$= -\mu \, \frac{\partial u}{\partial y} \bigg]_{y=0} + \int_0^\delta \rho g \beta (T - T_\infty) \, dy$$
[7-6]





and we observe that the functional form of both the velocity and the temperature distributions must be known in order to arrive at the solution. To obtain these functions, we proceed in much the same way as in Chapter 5. The following conditions apply for the temperature distribution:

$$T = T_w$$
 at $y = 0$
 $T = T_\infty$ at $y = \delta$
 $\frac{\partial T}{\partial y} = 0$ at $y = \delta$

so that we obtain for the temperature distribution

$$\frac{T - T_{\infty}}{T_w - T_{\infty}} = \left(1 - \frac{y}{\delta}\right)^2$$
 [7-7]

Three conditions for the velocity profile are

$$u = 0$$
 at $y = 0$
 $u = 0$ at $y = \delta$
 $\frac{\partial u}{\partial y} = 0$ at $y = \delta$

An additional condition may be obtained from Equation (7-4) by noting that

$$\frac{\partial^2 u}{\partial y^2} = -g\beta \frac{T_w - T_\infty}{v} \quad \text{at } y = 0$$

As in the integral analysis for forced-convection problems, we assume that the velocity profiles have geometrically similar shapes at various x distances along the plate. For the free-convection problem, we now assume that the velocity may be represented as a polynomial function of y multiplied by some arbitrary function of x. Thus,

$$\frac{u}{u_x} = a + by + cy^2 + dy^3$$

where u_x is a fictitious velocity that is a function of x. The cubic-polynomial form is chosen because there are four conditions to satisfy, and this is the simplest type of function that may be used. Applying the four conditions to the velocity profile listed above, we have

$$\frac{u}{u_x} = \frac{\beta \delta^2 g(T_w - T_\infty)}{4u_x \nu} \frac{y}{\delta} \left(1 - \frac{y}{\delta}\right)^2$$

The term involving the temperature difference, δ^2 , and u_x may be incorporated into the function u_x so that the final relation to be assumed for the velocity profile is

$$\frac{u}{u_x} = \frac{y}{\delta} \left(1 - \frac{y}{\delta} \right)^2$$
 [7-8]

A plot of Equation (7-8) is given in Figure 7-2. Substituting Equations (7-7) and (7-8) into Equation (7-6) and carrying out the integrations and differentiations yields

$$\frac{1}{105}\frac{d}{dx}(u_x^2\delta) = \frac{1}{3}g\beta(T_w - T_\infty)\delta - v\frac{u_x}{\delta}$$
 [7-9]

The integral form of the energy equation for the free-convection system is


$$\frac{d}{dx} \left[\int_0^\delta u(T - T_\infty) dy \right] = -\alpha \frac{dT}{dy} \bigg|_{y=0}$$
 [7-10]





7-2 Free-Convection Heat Transfer on a Vertical Flat Plate

Figure 7-2 | Free-convection velocity profile given by Equation (7-8).



and when the assumed velocity and temperature distributions are inserted into this equation and the operations are performed, there results

$$\frac{1}{30}(T_w - T_\infty) \frac{d}{dx}(u_x \delta) = 2\alpha \frac{T_w - T_\infty}{\delta}$$
 [7-11]

It is clear from the reasoning that led to Equation (7-8) that

$$u_x \sim \delta^2$$
 [7-12]

Inserting this type of relation in Equation (7-9) yields the result that

$$\delta \sim x^{1/4}$$
 [7-13]

We therefore assume the following exponential functional variations for u_x and δ :

$$u_x = C_1 x^{1/2} [7-14]$$

$$\delta = C_2 x^{1/4}$$
 [7-15]

Introducing these relations into Equations (7-9) and (7-11) gives

$$\frac{5}{420}C_1^2C_2x^{1/4} = g\beta(T_w - T_\infty)\frac{C_2}{3}x^{1/4} - \frac{C_1}{C_2}\nu x^{1/4}$$
 [7-16]

and

$$\frac{1}{40}C_1C_2x^{-1/4} = \frac{2\alpha}{C_2}x^{-1/4}$$
 [7-17]

These two equations may be solved for the constants C_1 and C_2 to give

$$C_1 = 5.17\nu \left(\frac{20}{21} + \frac{\nu}{\alpha}\right)^{-1/2} \left\lceil \frac{g\beta(T_w - T_\infty)}{\nu^2} \right\rceil^{1/2}$$
 [7-18]

$$C_2 = 3.93 \left(\frac{20}{21} + \frac{\nu}{\alpha}\right)^{1/4} \left[\frac{g\beta(T_w - T_\infty)}{\nu^2}\right]^{-1/4} \left(\frac{\nu}{\alpha}\right)^{-1/2}$$
 [7-19]

The resultant expressions for the boundary layer thickness and fictitious velocity u_x are

$$\frac{\delta}{x} = 3.93 \,\mathrm{Pr}^{-1/2} (0.952 + \mathrm{Pr})^{1/4} \mathrm{Gr}_{x}^{-1/4}$$
 [7-20a]





$$u_x = 5.17(0.952 + \text{Pr})^{-1/2} \text{Gr}_x^{1/2}$$
 [7-20b]

The velocity profile shown in Figure 7-2 has its maximum value at $y/\delta = 1/3$, giving $u_{\text{max}} = (4/27)u_x = 0.148u_x$. The mass flow through the boundary layer at any x position may be determined by evaluating the integral

$$\dot{m} = \int \rho u \, dy = \int_{0}^{\delta} \rho u_x \, \frac{y}{\delta} \, \left(1 - \frac{y}{\delta} \right)^2 \, dy = \frac{1}{12} \, \rho u_x \delta = 0.083 \, \rho u_x \delta = \frac{9}{16} \, \rho u_{\text{max}} \delta \qquad [7-20c]$$

The respective values of δ and u_x determined from Equations (7-20a) and (7-20b) may be inserted to obtain the mass flow values.

The Prandtl number $Pr = v/\alpha$ has been introduced in the above expressions along with a new dimensionless group called the *Grashof number* Gr_x :

$$Gr_x = \frac{g\beta(T_w - T_\infty)x^3}{v^2}$$
 [7-21]

The heat-transfer coefficient may be evaluated from

$$q_w = -kA \left. \frac{dT}{dy} \right]_w = hA(T_w - T_\infty)$$

Using the temperature distribution of Equation (7-7), one obtains

$$h = \frac{2k}{\delta}$$
 or $\frac{hx}{k} = \text{Nu}_x = 2\frac{x}{\delta}$

so that the dimensionless equation for the heat-transfer coefficient becomes

$$Nu_x = 0.508 Pr^{1/2} (0.952 + Pr)^{-1/4} Gr_x^{1/4}$$
 [7-22]

Equation (7-22) gives the variation of the local heat-transfer coefficient along the vertical plate. The average heat-transfer coefficient may then be obtained by performing the integration

$$\overline{h} = \frac{1}{L} \int_0^L h_x dx$$
 [7-23]

For the variation given by Equation (7-22), the average coefficient is

$$\overline{h} = \frac{4}{3}h_{x=L} \tag{7-24}$$

The Grashof number may be interpreted physically as a dimensionless group representing the ratio of the buoyancy forces to the viscous forces in the free-convection flow system. It has a role similar to that played by the Reynolds number in forced-convection systems and is the primary variable used as a criterion for transition from laminar to turbulent boundary-layer flow. For air in free convection on a vertical flat plate, the critical Grashof number has been observed by Eckert and Soehngen [1] to be approximately 4×10^8 . Values ranging between 10^8 and 10^9 may be observed for different fluids and environment "turbulence levels."

A very complete survey of the stability and transition of free-convection boundary layers has been given by Gebhart et al. [13–15].

The foregoing analysis of free-convection heat transfer on a vertical flat plate is the simplest case that may be treated mathematically, and it has served to introduce the new





7-3 Empirical Relations for Free Convection

Figure 7-3 | Pulsed free-convection boundary layer on vertical flat plate. Distance between letters = 5 cm.



dimensionless variable, the Grashof number,[†] which is important in all free-convection problems. But as in some forced-convection problems, experimental measurements must be relied upon to obtain relations for heat transfer in other circumstances. These circumstances are usually those in which it is difficult to predict temperature and velocity profiles analytically. Turbulent free convection is an important example, just as is turbulent forced convection, of a problem area in which experimental data are necessary; however, the problem is more acute with free-convection flow systems than with forced-convection systems because the velocities are usually so small that they are very difficult to measure. For example, the maximum free-convection velocity experienced by a vertical plate heated to 45°C and exposed to atmospheric room air at 25°C is only about 350 mm/s. Despite the experimental difficulties, velocity measurements have been performed using hydrogen-bubble techniques [26], hot-wire anemometry [28], and quartz-fiber anemometers. Temperature field measurements have been obtained through the use of the Zehnder-Mach interferometer. The laser anemometer [29] is particularly useful for free-convection measurements because it does not disturb the flow field.

An interferometer indicates lines of constant density in a fluid flow field. For a gas in free convection at low pressure these lines of constant density are equivalent to lines of constant temperature. Once the temperature field is obtained, the heat transfer from a surface in free convection may be calculated by using the temperature gradient at the surface and the thermal conductivity of the gas. Several interferometric studies of free convection have been made [1-3], and Figure 7-3 indicates the isotherms in a free-convection boundary layer on a vertical flat plate with $T_W = 48$ °C and $T_{\infty} = 20$ °C in room air. The spacing between the horizontal markers is about 2.5 cm, indicating a boundary-layer thickness of about that same value. The letter A corresponds to the leading edge of the plate. Note that the isotherms are more closely spaced near the plate surface, indicating a higher temperature gradient in that region. The oscillatory or "wave" shape of the boundary layer isotherms is caused by a heat pulse from a fine wire located at x = 2.5 cm and having a frequency of about 2.5 Hz. The pulse moves up the plate at about the boundary layer velocity, so an indication of the velocity profile may be obtained by connecting the maximum points in the isotherms. Such a profile is indicated in Figure 7-4. Eventually, at about $Gr = 10^8 - 10^9$ small oscillations in the boundary layer become amplified and transition to turbulence begins. The region shown in Figure 7-3 is all laminar.

A number of references treat the various theoretical and empirical aspects of free-convection problems. One of the most extensive discussions is given by Gebhart et. al. [13], and the interested reader may wish to consult this reference for additional information.

7-3 | EMPIRICAL RELATIONS FOR FREE CONVECTION

Over the years it has been found that average free-convection heat-transfer coefficients can be represented in the following functional form for a variety of circumstances:


$$\overline{\mathrm{Nu}}_f = C(\mathrm{Gr}_f \, \mathrm{Pr}_f)^m \tag{7-25}$$

[†]History is not clear on the point, but it appears that the Grashof number was named for Franz Grashof, a professor of applied mechanics at Karlsruhe around 1863 and one of the founding directors of *Verein deutscher Ingenieure* in 1855. He developed some early steam-flow formulas but made no significant contributions to free convection [36].





Figure 7-4 | Free-convection velocity profile indicated by connecting maximum points in boundary-layer isotherms of Figure 7-3.



where the subscript f indicates that the properties in the dimensionless groups are evaluated at the film temperature

$$T_f = \frac{T_{\infty} + T_w}{2}$$

The product of the Grashof and Prandtl numbers is called the Rayleigh number:

$$Ra = Gr Pr$$
 [7-26]

Characteristic Dimensions

The characteristic dimension to be used in the Nusselt and Grashof numbers depends on the geometry of the problem. For a vertical plate it is the height of the plate L; for a horizontal cylinder it is the diameter d; and so forth. Experimental data for free-convection problems appear in a number of references, with some conflicting results. The purpose of the sections that follow is to give these results in a summary form that may be easily used for calculation purposes. The functional form of Equation (7-25) is used for many of these presentations, with the values of the constants C and M specified for each case. Table 7-1 provides a summary of the values of these correlation constants for different geometries, and the sections that follow discuss the correlations in more detail.

For convenience of the reader, the present author has presented a graphical meld of the correlations for the isothermal vertical plate and horizontal cylinder configurations in the form of Figures 7-5 and 7-6. These figures may be used in lieu of the formulas when a quick estimate of performance is desired.





7-4 Free Convection from Vertical Planes and Cylinders

Table 7-1 Constants for use with Equation (7-25) for isothermal surfaces.

Geometry	$\operatorname{Gr}_f\operatorname{Pr}_f$	C	m	Reference(s)
Vertical planes and cylinders	$10^{-1} - 10^4$	Use Fig. 7-5	Use Fig. 7-5	4
	$10^4 - 10^9$	0.59	$\frac{1}{4}$	4
	$10^9 - 10^{13}$	0.021	$\frac{2}{5}$	30
	$10^9 - 10^{13}$	0.10	$\frac{1}{3}$	22, 16 [†]
Horizontal cylinders	$0-10^{-5}$	0.4	0	4
	$10^{-5} - 10^4$	Use Fig. 7-6	Use Fig. 7-6	4
	$10^4 - 10^9$	0.53	$\frac{1}{4}$	4
	$10^9 - 10^{12}$	0.13	$\frac{1}{3}$	4
	$10^{-10} - 10^{-2}$	0.675	0.058	76 [†]
	$10^{-2} - 10^2$	1.02	0.148	76^{\dagger}
	$10^2 - 10^4$	0.850	0.188	76
	$10^4 - 10^7$	0.480	$\frac{1}{4}$	76
	$10^7 - 10^{12}$	0.125		76
Upper surface of heated plates or lower surface of cooled plates	$2 \times 10^4 - 8 \times 10^6$	0.54	$\frac{\frac{1}{3}}{\frac{1}{4}}$	44, 52
Upper surface of heated plates or lower surface of cooled plates	$8 \times 10^6 - 10^{11}$	0.15	$\frac{1}{3}$	44, 52
Lower surface of heated plates or upper surface of cooled plates	$10^5 - 10^{11}$	0.27	$\frac{1}{4}$	44, 37, 75
Vertical cylinder, height = diameter characteristic length = diameter	$10^4 - 10^6$	0.775	0.21	77
Irregular solids, characteristic length = distance fluid particle travels in boundary layer	$10^4 - 10^9$	0.52	$\frac{1}{4}$	78

[†] Preferred.

7-4 | FREE CONVECTION FROM VERTICAL PLANES AND CYLINDERS

Isothermal Surfaces

For vertical surfaces, the Nusselt and Grashof numbers are formed with L, the height of the surface as the characteristic dimension. If the boundary-layer thickness is not large compared with the diameter of the cylinder, the heat transfer may be calculated with the same relations used for vertical plates. The general criterion is that a vertical cylinder may be treated as a vertical flat plate [13] when

$$\frac{D}{L} \ge \frac{35}{\text{Gr}_I^{1/4}}$$
 [7-27]

where D is the diameter of the cylinder. For vertical cylinders too small to meet this criteria, the analysis of Reference [84] for gases with Pr = 0.7 indicates that the flat plate results for the average heat-transfer coefficient should be multiplied by a factor F to account for the curvature, where


$$F = 1.3[(L/D)/Gr_D]^{1/4} + 1.0$$
 [7-27a]

For *isothermal* surfaces, the values of the constants C and m are given in Table 7-1 with the appropriate references noted for further consultation. The reader's attention is directed





Figure 7-5 | Free-convection heat transfer from vertical isothermal plates.



to the two sets of constants given for the turbulent case (${\rm Gr}_f {\rm Pr}_f > 10^9$). Although there may appear to be a decided difference in these constants, a comparison by Warner and Arpaci [22] of the two relations with experimental data indicates that both sets of constants fit available data. There are some indications from the analytical work of Bayley [16], as well as heat flux measurements of Reference 22, that the relation

$$Nu_f = 0.10(Gr_f Pr_f)^{1/3}$$

may be preferable.

More complicated relations have been provided by Churchill and Chu [71] that are applicable over wider ranges of the Rayleigh number:

$$\overline{Nu} = 0.68 + \frac{0.670 \text{ Ra}^{1/4}}{[1 + (0.492/\text{Pr})^{9/16}]^{4/9}} \qquad \text{for } \text{Ra}_L < 10^9$$

$$\overline{\mathrm{Nu}}^{1/2} = 0.825 + \frac{0.387 \; \mathrm{Ra}^{1/6}}{[1 + (0.492/\mathrm{Pr})^{9/16}]^{8/27}} \qquad \text{ for } 10^{-1} < \mathrm{Ra}_L < 10^{12} \qquad \text{[7-29]}$$


Equation (7-28) is also a satisfactory representation for constant heat flux. Properties for these equations are evaluated at the film temperature.





7-4 Free Convection from Vertical Planes and Cylinders

Figure 7-6 | Free-convection heat transfer from horizontal isothermal cylinders.



Constant-Heat-Flux Surfaces

Extensive experiments have been reported in References 25, 26, and 39 for free convection from vertical and inclined surfaces to water under constant-heat-flux conditions. In such experiments, the results are presented in terms of a modified Grashof number, Gr*:

$$Gr_x^* = Gr_x Nu_x = \frac{g\beta q_w x^4}{kv^2}$$
 [7-30]

where $q_w = q/A$ is the heat flux per unit area and is assumed constant over the entire plate surface area.

The *local* heat-transfer coefficients were correlated by the following relation for the laminar range:

$$Nu_{xf} = \frac{hx}{k_f} = 0.60(Gr_x^* Pr_f)^{1/5} \qquad 10^5 < Gr_x^* Pr < 10^{11}; q_w = const$$
 [7-31]

It is to be noted that the criterion for laminar flow expressed in terms of Gr_{x}^{*} is not the same as that expressed in terms of Gr_{x} . Boundary-layer transition was observed to begin between $Gr_{x}^{*} \Pr = 3 \times 10^{12}$ and 4×10^{13} and to end between 2×10^{13} and 10^{14} . Fully developed turbulent flow was present by $Gr_{x}^{*} \Pr = 10^{14}$, and the experiments were extended up to $Gr_{x}^{*} \Pr = 10^{16}$. For the turbulent region, the local heat-transfer coefficients are correlated with

$$Nu_x = 0.17(Gr_x^* Pr)^{1/4}$$
 $2 \times 10^{13} < Gr_x^* Pr < 10^{16}; q_w = const$ [7-32]





All properties in Equations (7-31) and (7-32) are evaluated at the local film temperature. Although these experiments were conducted for water, the resulting correlations are shown to work for air as well. The average heat-transfer coefficient for the constant-heat-flux case may not be evaluated from Equation (7-24) but must be obtained through a separate application of Equation (7-23). Thus, for the laminar region, using Equation (7-31) to evaluate h_x ,

$$\overline{h} = \frac{1}{L} \int_0^L h_x dx$$

$$\overline{h} = \frac{5}{4} h_{x=L} \qquad q_w = \text{const}$$

At this point we may note the relationship between the correlations in the form of Equation (7-25) and those just presented in terms of $Gr_x^* = Gr_x Nu_x$. Writing Equation (7-25) as a *local* heat-transfer form gives

$$Nu_r = C(Gr_r Pr)^m$$
 [7-33]

Inserting $Gr_x = Gr_x^*/Nu_x$ gives

$$Nu_x^{1+m} = C(Gr_x^* Pr)^m$$

or

$$Nu_x = C^{1/(1+m)} (Gr_x^* Pr)^{m/(1+m)}$$
 [7-34]

Thus, when the "characteristic" values of m for laminar and turbulent flow are compared to the exponents on Gr_x^* , we obtain

Laminar,
$$m = \frac{1}{4}$$
:
$$\frac{m}{1+m} = \frac{1}{5}$$

Turbulent, $m = \frac{1}{3}$:
$$\frac{m}{1+m} = \frac{1}{4}$$

While the Gr* formulation is easier to employ for the constant-heat-flux case, we see that the characteristic exponents fit nicely into the scheme that is presented for the isothermal surface correlations.

It is also interesting to note the variation of h_x with x in the two characteristic regimes. For the laminar range $m = \frac{1}{4}$, and from Equation (7-25)

$$h_x \sim \frac{1}{x} (x^3)^{1/4} = x^{-1/4}$$

In the turbulent regime $m = \frac{1}{3}$, and we obtain

$$h_x \sim \frac{1}{x} (x^3)^{1/3} = \text{const with } x$$

So when turbulent free convection is encountered, the local heat-transfer coefficient is essentially constant with x.

Churchill and Chu [71] show that Equation (7-28) may be modified to apply to the constant-heat-flux case if the average Nusselt number is based on the wall heat flux and the temperature difference at the center of the plate (x = L/2). The result is

$$\overline{\mathrm{Nu}}_{L}^{1/4}(\overline{\mathrm{Nu}}_{L}-0.68) = \frac{0.67(\mathrm{Gr}_{L}^{*}\,\mathrm{Pr})^{1/4}}{[1+(0.492/\mathrm{Pr})^{9/16}]^{4/9}} \tag{7-35}$$

where $\overline{\mathrm{Nu}}_L = q_w L/(k\overline{\Delta T})$ and $\overline{\Delta T} = T_w - T_\infty$ at $L/2 - T_\infty$.





•

EXAMPLE 7-1

Constant Heat Flux from Vertical Plate

In a plant location near a furnace, a net radiant energy flux of 800 W/m² is incident on a vertical metal surface 3.5 m high and 2 m wide. The metal is insulated on the back side and painted black so that all the incoming radiation is lost by free convection to the surrounding air at 30°C. What average temperature will be attained by the plate?

Solution

We treat this problem as one with constant heat flux on the surface. Since we do not know the surface temperature, we must make an estimate for determining T_f and the air properties. An approximate value of h for free-convection problems is $10 \text{ W/m}^2 \cdot {}^{\circ}\text{C}$, and so, approximately,

$$\Delta T = \frac{q_w}{h} \approx \frac{800}{10} = 80^{\circ} \text{C}$$

Then

$$T_f \approx \frac{80}{2} + 30 = 70^{\circ} \text{C} = 343 \text{ K}$$

At 70°C the properties of air are

$$\nu = 2.043 \times 10^{-5} \,\mathrm{m}^2/\mathrm{s}$$
 $\beta = \frac{1}{T_f} = 2.92 \times 10^{-3} \,\mathrm{K}^{-1}$ $k = 0.0295 \,\mathrm{W/m} \cdot ^{\circ}\mathrm{C}$ $\mathrm{Pr} = 0.7$

From Equation (7-30), with x = 3.5 m,

$$Gr_x^* = \frac{g\beta q_w x^4}{kv^2} = \frac{(9.8)(2.92 \times 10^{-3})(800)(3.5)^4}{(0.0295)(2.043 \times 10^{-5})^2} = 2.79 \times 10^{14}$$

We may therefore use Equation (7-32) to evaluate h_x :

$$h_x = \frac{k}{x} (0.17) (Gr_x^* Pr)^{1/4}$$

= $\frac{0.0295}{3.5} (0.17) (2.79 \times 10^{14} \times 0.7)^{1/4}$
= $5.36 \text{ W/m}^2 \cdot ^{\circ}\text{C} [0.944 \text{ Btu/h} \cdot \text{ft}^2 \cdot ^{\circ}\text{F}]$

In the turbulent heat transfer governed by Equation (7-32), we note that

$$\text{Nu}_x = \frac{hx}{k} \sim (\text{Gr}_x^*)^{1/4} \sim (x^4)^{1/4}$$

or h_x does not vary with x, and we may take this as the average value. The value of $h = 5.41 \text{ W/m}^2 \cdot ^{\circ}\text{C}$ is less than the approximate value we used to estimate T_f . Recalculating ΔT , we obtain

$$\Delta T = \frac{q_w}{h} = \frac{800}{5.36} = 149^{\circ} \text{C}$$

Our new film temperature would be

$$T_f = 30 + \frac{149}{2} = 104.5$$
°C

At 104.5°C the properties of air are

$$\nu = 2.354 \times 10^{-5} \text{ m}^2/\text{s}$$
 $\beta = \frac{1}{T_f} = 2.65 \times 10^{-3}/\text{K}$
 $k = 0.0320 \text{ W/m} \cdot ^{\circ}\text{C}$ Pr = 0.695





Then

$$Gr_x^* = \frac{(9.8)(2.65 \times 10^{-3})(800)(3.5)^4}{(0.0320)(2.354 \times 10^{-5})^2} = 1.75 \times 10^{14}$$

and h_x is calculated from

$$\begin{split} h_{x} &= \frac{k}{x} (0.17) (\text{Gr}_{x}^{*} \, \text{Pr})^{1/4} \\ &= \frac{(0.0320)(0.17)}{3.5} [(1.758 \times 10^{14})(0.695)]^{1/4} \\ &= 5.17 \, \text{W/m}^{2} \cdot ^{\circ}\text{C} \, [-0.91 \, \text{Btu/h} \cdot \text{ft}^{2} \cdot ^{\circ}\text{F}] \end{split}$$

Our new temperature difference is calculated as

$$\Delta T = (T_w - T_\infty)_{av} = \frac{q_w}{h} = \frac{800}{5.17} = 155^{\circ} \text{C}$$

The average wall temperature is therefore

$$T_{w,av} = 155 + 30 = 185$$
°C

Another iteration on the value of T_f is not warranted by the improved accuracy that would result.

Heat Transfer from Isothermal Vertical Plate

EXAMPLE 7-2

A large vertical plate 4.0 m high is maintained at 60° C and exposed to atmospheric air at 10° C. Calculate the heat transfer if the plate is 10 m wide.

■ Solution

We first determine the film temperature as

$$T_f = \frac{60 + 10}{2} = 35^{\circ} \text{C} = 308 \text{ K}$$

The properties of interest are thus

$$\beta = \frac{1}{308} = 3.25 \times 10^{-3} \qquad k = 0.02685$$

$$v = 16.5 \times 10^{-6} \qquad \text{Pr} = 0.7$$

and

Gr Pr =
$$\frac{(9.8)(3.25 \times 10^{-3})(60 - 10)(4)^3}{(16.5 \times 10^{-6})^2} 0.7$$
$$= 2.62 \times 10^{11}$$

We then may use Equation (7-29) to obtain

$$\begin{split} \overline{Nu}^{1/2} &= 0.825 + \frac{(0.387)(2.62 \times 10^{11})^{1/6}}{[1 + (0.492/0.7)^{9/16}]^{8/27}} \\ &= 26.75 \\ \overline{Nu} &= 716 \end{split}$$

The heat-transfer coefficient is then

$$\overline{h} = \frac{(716)(0.02685)}{4.0} = 4.80 \text{ W/m}^2 \cdot {}^{\circ}\text{C}$$





7-5 Free Convection from Horizontal Cylinders

The heat transfer is

$$q = \overline{h}A(T_w - T_\infty)$$

= (4.80)(4)(10)(60 - 10) = 9606 W

As an alternative, we could employ the simpler relation

$$Nu = 0.10(Gr Pr)^{1/3}$$

= $(0.10)(2.62 \times 10^{11})^{1/3} = 639.9$

which gives a value about 10 percent lower than Equation (7-29).

7-5 | FREE CONVECTION FROM HORIZONTAL CYLINDERS

The values of the constants C and m are given in Table 7-1 according to References 4 and 76. The predictions of Morgan (Reference 76 in Table 7-1) are the most reliable for Gr Pr of approximately 10^{-5} . A more complicated expression for use over a wider range of Gr Pr is given by Churchill and Chu [70]:

$$\overline{Nu}^{1/2} = 0.60 + 0.387 \left\{ \frac{Gr \ Pr}{[1 + (0.559/Pr)^{9/16}]^{16/9}} \right\}^{1/6} \quad \text{for } 10^{-5} < Gr \ Pr \\ < 10^{12} \quad \textbf{[7-36]}$$

A simpler equation is available from Reference 70 but is restricted to the laminar range of $10^{-6} < Gr \, Pr < 10^9$:

$$Nu_d = 0.36 + \frac{0.518(Gr_d Pr)^{1/4}}{[1 + (0.559/Pr)^{9/16}]^{4/9}}$$
 [7-37]

Properties in Equations (7-36) and (7-37) are evaluated at the film temperature.

Heat transfer from horizontal cylinders to liquid metals may be calculated from Reference 46:

$$Nu_d = 0.53(Gr_d Pr^2)^{1/4}$$
 [7-38]

EXAMPLE 7-3

Heat Transfer from Horizontal Tube in Water

A 2.0-cm-diameter horizontal heater is maintained at a surface temperature of 38°C and submerged in water at 27°C. Calculate the free-convection heat loss per unit length of the heater.

■ Solution

The film temperature is

$$T_f = \frac{38 + 27}{2} = 32.5$$
°C

From Appendix A the properties of water are

$$k = 0.630 \text{ W/m} \cdot ^{\circ}\text{C}$$

and the following term is particularly useful in obtaining the Gr Pr product when it is multiplied by $d^3\Delta T$:

$$\frac{g\beta\rho^2c_p}{\mu k} = 2.48 \times 10^{10}$$
 [1/m³·°C]





Gr Pr =
$$(2.48 \times 10^{10})(38 - 27)(0.02)^3 = 2.18 \times 10^6$$

Using Table 7-1, we get C = 0.53 and $m = \frac{1}{4}$, so that

$$Nu = (0.53)(2.18 \times 10^6)^{1/4} = 20.36$$

$$h = \frac{(20.36)(0.63)}{0.02} = 642 \text{ W/m}^2 \cdot ^{\circ}\text{C}$$

The heat transfer is thus

$$\frac{q}{L} = h\pi d(T_w - T_\infty)$$
= (642)\pi(0.02)(38 - 27) = 443 W/m

Heat Transfer from Fine Wire in Air

EXAMPLE 7-4

A fine wire having a diameter of 0.02 mm is maintained at a constant temperature of 54° C by an electric current. The wire is exposed to air at 1 atm and 0° C. Calculate the electric power necessary to maintain the wire temperature if the length is 50 cm.

■ Solution

The film temperature is $T_f = (54 + 0)/2 = 27^{\circ} \text{C} = 300 \text{ K}$, so the properties are

$$\beta = 1/300 = 0.00333$$
 $\nu = 15.69 \times 10^{-6} \text{ m}^2/\text{s}$
 $k = 0.02624 \text{ W/m} \cdot ^{\circ}\text{C}$ $\text{Pr} = 0.708$

The Gr Pr product is then calculated as

Gr Pr =
$$\frac{(9.8)(0.00333)(54-0)(0.02\times10^{-3})^3}{(15.69\times10^{-6})^2}(0.708) = 4.05\times10^{-5}$$

From Table 7-1 we find C = 0.675 and m = 0.058 so that

$$\overline{\text{Nu}} = (0.675)(4.05 \times 10^{-5})^{0.058} = 0.375$$

and

$$\overline{h} = \overline{\text{Nu}} \left(\frac{k}{d} \right) = \frac{(0.375)(0.02624)}{0.02 \times 10^{-3}} = 492.6 \text{ W/m}^2 \cdot {}^{\circ}\text{C}$$

The heat transfer or power required is then

$$q = \overline{h}A(T_w - T_\infty) = (492.6)\pi(0.02 \times 10^{-3})(0.5)(54 - 0) = 0.836 \text{ W}$$

Heated Horizontal Pipe in Air

EXAMPLE 7-5

A horizontal pipe 1 ft (0.3048 m) in diameter is maintained at a temperature of 250° C in a room where the ambient air is at 15° C. Calculate the free-convection heat loss per meter of length.

■ Solution

We first determine the Grashof-Prandtl number product and then select the appropriate constants from Table 7-1 for use with Equation (7-25). The properties of air are evaluated at the film temperature:

$$T_f = \frac{T_w + T_\infty}{2} = \frac{250 + 15}{2} = 132.5$$
°C = 405.5 K





7-6 Free Convection from Horizontal Plates

$$k = 0.03406 \text{ W/m} \cdot {}^{\circ}\text{C} \qquad \beta = \frac{1}{T_f} = \frac{1}{405.5} = 2.47 \times 10^{-3} \text{ K}^{-1}$$

$$\nu = 26.54 \times 10^{-6} \text{ m}^2/\text{s} \qquad \text{Pr} = 0.687$$

$$Gr_d \Pr = \frac{g\beta(T_w - T_\infty)d^3}{v^2} \Pr$$

$$= \frac{(9.8)(2.47 \times 10^{-3})(250 - 15)(0.3048)^3(0.687)}{(26.54 \times 10^{-6})^2}$$

$$= 1.571 \times 10^8$$

From Table 7-1, C = 0.53 and $m = \frac{1}{4}$, so that

$$Nu_d = 0.53(Gr_d Pr)^{1/4} = (0.53)(1.571 \times 10^8)^{1/4} = 59.4$$

$$h = \frac{kNu_d}{d} = \frac{(0.03406)(59.4)}{0.3048} = 6.63 \text{ W/m}^2 \cdot ^{\circ}\text{C} \quad [1.175 \text{ Btu/h} \cdot \text{ft}^2 \cdot ^{\circ}\text{F}]$$

The heat transfer per unit length is then calculated from

$$\frac{q}{L} = h\pi \, d(T_w - T_\infty) = 6.63\pi (0.3048)(250 - 15) = 1.49 \text{ kW/m} \quad [1560 \text{ Btu/h} \cdot \text{ft}]$$

As an alternative, we could employ the more complicated expression, Equation (7-36), for solution of the problem. The Nusselt number thus would be calculated as

$$\overline{\text{Nu}}^{1/2} = 0.60 + 0.387 \left\{ \frac{1.571 \times 10^8}{[1 + (0.559/0.687)^{9/16}]^{16/9}} \right\}^{1/6}$$

or a value about 8 percent higher.

7-6 | FREE CONVECTION FROM HORIZONTAL PLATES

Isothermal Surfaces

The average heat-transfer coefficient from horizontal flat plates is calculated with Equation (7-25) and the constants given in Table 7-1. The characteristic dimension for use with these relations has traditionally [4] been taken as the length of a side for a square, the mean of the two dimensions for a rectangular surface, and 0.9d for a circular disk. References 52 and 53 indicate that better agreement with experimental data can be achieved by calculating the characteristic dimension with

$$L = \frac{A}{P}$$
 [7-39]

where A is the area and P is the perimeter of the surface. This characteristic dimension is also applicable to unsymmetrical planforms.

Constant Heat Flux

The experiments of Reference 44 have produced the following correlations for constant heat flux on a horizontal plate. For the heated surface facing upward,

$$\overline{\text{Nu}}_L = 0.13 (\text{Gr}_L \text{ Pr})^{1/3}$$
 for $\text{Gr}_L \text{ Pr} < 2 \times 10^8$ [7-40]





and

$$\overline{\text{Nu}}_L = 0.16 (\text{Gr}_L \text{ Pr})^{1/3}$$
 for $2 \times 10^8 < \text{Gr}_L \text{ Pr} < 10^{11}$ [7-41]

For the heated surface facing downward,

$$\overline{\text{Nu}}_L = 0.58(\text{Gr}_L \text{Pr})^{1/5}$$
 for $10^6 < \text{Gr}_L \text{Pr} < 10^{11}$ [7-42]

In these equations all properties except β are evaluated at a temperature T_e defined by

$$T_e = T_w - 0.25(T_w - T_\infty)$$

and T_w is the average wall temperature related, as before, to the heat flux by

$$\overline{h} = \frac{q_w}{T_w - T_\infty}$$

The Nusselt number is formed as before:

$$\overline{\text{Nu}}_L = \frac{\overline{h}L}{k} = \frac{q_w L}{(T_w - T_\infty)k}$$

Section 7-7 discusses an extension of these equations to inclined surfaces.

Irregular Solids

There is no general correlation which can be applied to irregular solids. The results of Reference 77 indicate that Equation (7-25) may be used with C=0.775 and m=0.208 for a vertical cylinder with height equal to diameter. Nusselt and Grashof numbers are evaluated by using the diameter as characteristic length. Lienhard [78] offers a prescription that takes the characteristic length as the distance a fluid particle travels in the boundary layer and uses values of C=0.52 and $m=\frac{1}{4}$ in Equation (7-25) in the laminar range. This may serve as an estimate for calculating the heat-transfer coefficient in the absence of specific information on a particular geometric shape. Bodies of unity aspect ratio are studied extensively in Reference 81.

Cube Cooling in Air

EXAMPLE 7-6

A cube, 20 cm on a side, is maintained at 60° C and exposed to atmospheric air at 10° C. Calculate the heat transfer.

■ Solution

This is an irregular solid so we use the information in the last entry of Table 7-1 in the absence of a specific correlation for this geometry. The properties were evaluated in Example 7-2 as

$$\beta = 3.25 \times 10^{-3}$$
 $k = 0.02685$
 $v = 17.47 \times 10^{-6}$ $Pr = 0.7$

The characteristic length is the distance a particle travels in the boundary layer, which is L/2 along the bottom plus L along the side plus L/2 on the top, or 2L=40 cm. The Gr Pr product is thus:

$$Gr Pr = \frac{(9.8)(3.25 \times 10^{-3})(60 - 10)(0.4)^3}{(17.47 \times 10^{-6})^2}(0.7) = 2.34 \times 10^8$$

From the last entry in Table 7-1 we find C = 0.52 and n = 1/4 and calculate the Nusselt number as

$$Nu = (0.52)(2.34 \times 10^8)^{1/4} = 64.3$$





7-7 Free Convection from Inclined Surfaces

and


$$\overline{h} = \text{Nu} \frac{k}{L} = \frac{(64.3)(0.02685)}{(0.4)} = 4.32 \text{ W/m}^2 \cdot ^{\circ}\text{C}$$

The cube has six sides so the area is $6(0.2)^2 = 0.24 \text{ m}^2$ and the heat transfer is

$$q = \overline{h}A(T_w - T_\infty) = (4.32)(0.24)(60 - 10) = 51.8 \text{ W}$$

7-7 | FREE CONVECTION FROM INCLINED SURFACES

Figure 7-7 | Coordinate system for inclined plates.



Extensive experiments have been conducted by Fujii and Imura [44] for heated plates in water at various angles of inclination. The angle that the plate makes with the vertical is designated θ , with positive angles indicating that the heater surface faces downward, as shown in Figure 7-7. For the inclined plate facing downward with approximately constant heat flux, the following correlation was obtained for the average Nusselt number:

$$\overline{Nu}_e = 0.56(Gr_e Pr_e \cos \theta)^{1/4}$$
 $\theta < 88^\circ; 10^5 < Gr_e Pr_e \cos \theta < 10^{11}$ [7-43]

In Equation (7-43) all properties except β are evaluated at a reference temperature T_e defined by

$$T_e = T_w - 0.25(T_w - T_\infty)$$
 [7-44]

where T_w is the *mean* wall temperature and T_∞ is the free-stream temperature; β is evaluated at a temperature of $T_\infty + 0.50(T_w - T_\infty)$. For almost-horizontal plates facing downward, that is, $88^\circ < \theta < 90^\circ$, an additional relation was obtained as

$$\overline{Nu}_e = 0.58(Gr_e Pr_e)^{1/5}$$
 $10^6 < Gr_e Pr_e < 10^{11}$ [7-45]

For an inclined plate with heated surface facing upward the empirical correlations become more complicated. For angles between -15 and -75° a suitable correlation is

$$\overline{Nu}_{e} = 0.14[(Gr_{e}Pr_{e})^{1/3} - (Gr_{e}Pr_{e})^{1/3}] + 0.56(Gr_{e}Pr_{e}\cos\theta)^{1/4}$$
 [7-46]

for the range $10^5 < {\rm Gr}_e \ {\rm Pr}_e \cos \theta < 10^{11}$. The quantity ${\rm Gr}_c$ is a critical Grashof relation indicating when the Nusselt number starts to separate from the laminar relation of Equation (7-43) and is given in the following tabulation:

θ , degrees	Gr_c
-15	5×10^{9}
-30	2×10^{9}
-60	10^{8}
-75	10^{6}

For $Gr_e < Gr_c$ the first term of Equation (7-46) is dropped out. Additional information is given by Vliet [39] and Pera and Gebhart [45]. There is some evidence to indicate that the above relations may also be applied to constant-temperature surfaces.

Experimental measurements with air on constant-heat-flux surfaces [51] have shown that Equation (7-31) may be employed for the laminar region if we replace Gr_x^* by $Gr_x^* \cos \theta$





for both upward- and downward-facing heated surfaces. In the turbulent region with air, the following empirical correlation was obtained:

$$Nu_x = 0.17(Gr_x^* Pr)^{1/4}$$
 $10^{10} < Gr_x^* Pr < 10^{15}$ [7-47]

where the Gr_{χ}^* is the same as for the vertical plate when the heated surface faces upward. When the heated surface faces downward, Gr_{χ}^* is replaced by $Gr^* \cos^2 \theta$. Equation (7-47) reduces approximately to the relation recommended in Table 7-1 for an isothermal vertical plate.

For inclined cylinders the data of Reference 73 indicate that laminar heat transfer under constant-heat-flux conditions may be calculated with the following relation:

$$Nu_L = [0.60 - 0.488(\sin \theta)^{1.03}](Gr_L Pr)^{\frac{1}{4} + \frac{1}{12}(\sin \theta)^{1.75}} \qquad \text{for } Gr_L Pr < 2 \times 10^8 \quad \textbf{[7-48]}$$

where θ is the angle the cylinder makes with the vertical; that is, 0° corresponds to a vertical cylinder. Properties are evaluated at the film temperature except β , which is evaluated at ambient conditions.

Uncertainties still remain in the prediction of free convection from inclined surfaces, and an experimental-data scatter of \pm 20 percent is not unusual for the empirical relations presented above.

7-8 | NONNEWTONIAN FLUIDS

When the shear-stress viscosity relation of the fluid does not obey the simple newtonian expression of Equation (5-1), the above equations for free-convection heat transfer do not apply. Extremely viscous polymers and lubricants are examples of fluids with nonnewtonian behavior. Successful analytical and experimental studies have been carried out with such fluids, but the results are very complicated. The interested reader should consult References 48 to 50 for detailed information on this subject.

7-9 | SIMPLIFIED EQUATIONS FOR AIR

Simplified equations for the heat-transfer coefficient from various surfaces to air at atmospheric pressure and moderate temperatures are given in Table 7-2. These relations may be extended to higher or lower pressures by multiplying by the following factors:

$$\left(\frac{p}{101.32}\right)^{1/2}$$
 for laminar cases $\left(\frac{p}{101.32}\right)^{2/3}$ for turbulent cases

where p is the pressure in kilopascals. Due caution should be exercised in the use of these simplified relations because they are only approximations of the more precise equations stated earlier.

The reader will note that the use of Table 7-2 requires a knowledge of the value of the Grashof-Prandtl number product. This might seem to be self-defeating, in that another calculation is required. However, with a bit of experience one learns the range of Gr Pr to be expected in various geometrical-physical situations, and thus the simplified expressions can be an expedient for quick problem solving. As we have noted, they are not a substitute for the more comprehensive expressions.





7-10 Free Convection from Spheres

Table 7-2 | Simplified equations for free convection from various surfaces to air at atmospheric pressure, adapted from Table 7-1.

	Laminar,	Turbulent,	
Surface	$10^4 < \text{Gr}_f \text{Pr}_f < 10^9$	$Gr_f Pr_f > 10^9$	
Vertical plane or cylinder	$h = 1.42 \left(\frac{\Delta T}{L}\right)^{1/4}$	$h = 1.31(\Delta T)^{1/3}$	
Horizontal cylinder	$h = 1.32 \left(\frac{\Delta T}{d}\right)^{1/4}$	$h = 1.24(\Delta T)^{1/3}$	
Horizontal plate:	1/4		
Heated plate facing upward or cooled plate facing downward	$h = 1.32 \left(\frac{\Delta T}{L}\right)^{1/4}$	$h = 1.52(\Delta T)^{1/3}$	
Heated plate facing downward or cooled plate facing upward	$h = 0.59 \left(\frac{\Delta T}{L}\right)^{1/4}$		
Heated cube; $L = \text{length of}$ side, Area = $6L^2$	$h = 1.052 \left(\frac{\Delta T}{L}\right)^{1/4}$		
	where $h=$ heat-transfer coefficient, W/m $^2\cdot ^\circ$ C $\Delta T=T_w-T_\infty, ^\circ$ C $L=$ vertical or horizontal dimension, m $d=$ diameter, m		

EXAMPLE 7-7

Calculation with Simplified Relations

Compute the heat transfer for the conditions of Example 7-5 using the simplified relations of Table 7-2.

■ Solution

In Example 7-5 we found that a rather large pipe with a substantial temperature difference between the surface and air still had a Gr Pr product of $1.57 \times 10^8 < 10^9$, so a laminar equation is selected from Table 7-2. The heat-transfer coefficient is given by

$$h = 1.32 \left(\frac{\Delta T}{d}\right)^{1/4} = 1.32 \left(\frac{250 - 15}{0.3048}\right)^{1/4}$$
$$= 6.96 \text{ W/m}^2 \cdot {}^{\circ}\text{C}$$

The heat transfer is then

$$\frac{q}{L} = (6.96)\pi(0.3048)(250 - 15) = 1.57 \text{ kW/m}$$

Note that the simplified relation gives a value approximately 4 percent higher than Equation (7-25).

7-10 | FREE CONVECTION FROM SPHERES

Yuge [5] recommends the following empirical relation for free-convection heat transfer from spheres to air:

$$Nu_f = \frac{\overline{h}d}{k_f} = 2 + 0.392 \text{ Gr}_f^{1/4}$$
 for $1 < Gr_f < 10^5$ [7-49]

This equation may be modified by the introduction of the Prandtl number to give

$$Nu_f = 2 + 0.43(Gr_f Pr_f)^{1/4}$$
 [7-50]





Properties are evaluated at the film temperature, and it is expected that this relation would be primarily applicable to calculations for free convection in gases. However, in the absence of more specific information it may also be used for liquids. We may note that for very low values of the Grashof-Prandtl number product the Nusselt number approaches a value of 2.0. This is the value that would be obtained for pure conduction through an infinite stagnant fluid surrounding the sphere, as obtained from Table 3-1.

For higher ranges of the Rayleigh number the experiments of Amato and Tien [79] with water suggest the following correlation:

$$Nu_f = 2 + 0.50(Gr_f Pr_f)^{1/4}$$
 [7-51]

for $3 \times 10^5 < Gr Pr < 8 \times 10^8$.

Churchill [83] suggests a more general formula for spheres, applicable over a wider range of Rayleigh numbers:

Nu = 2 +
$$\frac{0.589 \text{Ra}_d^{1/4}}{[1 + (0.469/\text{Pr})^{9/16}]^{4/9}}$$
 [7-52]

for $Ra_d < 10^{11}$ and Pr > 0.5.

7-11 | FREE CONVECTION IN ENCLOSED SPACES

The free-convection flow phenomena inside an enclosed space are interesting examples of very complex fluid systems that may yield to analytical, empirical, and numerical solutions. Consider the system shown in Figure 7-8, where a fluid is contained between two vertical plates separated by the distance δ . As a temperature difference $\Delta T_w = T_1 - T_2$ is impressed on the fluid, a heat transfer will be experienced with the approximate flow regions shown in Figure 7-9, according to MacGregor and Emery [18]. In this figure, the Grashof number

Figure 7-9 | Schematic diagram and flow regimes for the vertical convection layer, according to Reference 18.





Figure 7-8 | Nomenclature for free convection in enclosed vertical spaces.







7-11 Free Convection in Enclosed Spaces

is calculated as

$$Gr_{\delta} = \frac{g\beta(T_1 - T_2)\delta^3}{v^2}$$
 [7-53]

At very low Grashof numbers, there are very minute free-convection currents and the heat transfer occurs mainly by conduction across the fluid layer. As the Grashof number is increased, different flow regimes are encountered, as shown, with a progressively increasing heat transfer as expressed through the Nusselt number

$$\mathrm{Nu}_{\delta} = \frac{h\delta}{k}$$

Although some open questions still remain, the experiments of Reference 18 may be used to predict the heat transfer to a number of liquids under constant-heat-flux conditions. The empirical correlations obtained were:

Nu_{\delta} = 0.42(Gr_{\delta} Pr)^{1/4}Pr^{0.012}
$$\left(\frac{L}{\delta}\right)^{-0.30}$$
 $q_w = \text{const}$ [7-54]

$$10^4 < \text{Gr}_{\delta} \text{Pr} < 10^7$$

$$1 < \text{Pr} < 20,000$$

$$10 < L/\delta < 40$$

Nu_{$$\delta$$} = 0.46 (Gr _{δ} Pr)^{1/3} q_w = const [7-55]
 $10^6 < Gr_{\delta}$ Pr $< 10^9$
 $1 < Pr < 20$
 $1 < L/\delta < 40$

The heat flux is calculated as

$$\frac{q}{A} = q_w = h(T_1 - T_2) = Nu_\delta \frac{k}{\delta} (T_1 - T_2)$$
 [7-56]

The results are sometimes expressed in the alternate form of an *effective* or *apparent thermal* conductivity k_e , defined by

$$\frac{q}{A} = k_e \frac{T_1 - T_2}{\delta}$$
 [7-57]

By comparing Equations (7-56) and (7-57), we see that

$$Nu_{\delta} \equiv \frac{k_e}{k}$$
 [7-58]

In the building industry the heat transfer across an air gap is sometimes expressed in terms of the R values (see Section 2-3), so that

$$\frac{q}{A} = \frac{\Delta T}{R}$$

In terms of the above discussion, the R value would be


$$R = \frac{\delta}{k_c}$$
 [7-59]

Heat transfer in horizontal enclosed spaces involves two distinct situations. If the upper plate is maintained at a higher temperature than the lower plate, the lower-density fluid is above the higher-density fluid and no convection currents will be experienced. In this case





Figure 7-10 | Benard-cell pattern in enclosed fluid layer heated from below, from Reference 33.



the heat transfer across the space will be by conduction alone and $Nu_{\delta} = 1.0$, where δ is still the separation distance between the plates. The second, and more interesting, case is experienced when the lower plate has a higher temperature than the upper plate. For values of Gr_{δ} below about 1700, pure conduction is still observed and $Nu_{\delta} = 1.0$. As convection begins, a pattern of hexagonal cells is formed as shown in Figure 7-10. These patterns are called Benard cells [33]. Turbulence begins at about $Gr_{\delta} = 50,000$ and destroys the cellular pattern.

Free convection in inclined enclosures is discussed by Dropkin and Somerscales [12]. Evans and Stefany [9] have shown that transient natural-convection heating or cooling in closed vertical or horizontal cylindrical enclosures may be calculated with

$$Nu_f = 0.55(Gr_f Pr_f)^{1/4}$$
 [7-60]

for the range 0.75 < L/d < 2.0. The Grashof number is formed with the length of the cylinder L.

The analysis and experiments of Reference 43 indicate that it is possible to represent the effective thermal conductivity for fluids between concentric spheres with the relation

$$\frac{k_e}{k} = 0.228(\text{Gr}_{\delta} \text{Pr})^{0.226}$$
 [7-61]

where now the gap spacing is $\delta = r_o - r_i$. The effective thermal conductivity given by Equation (7-61) is to be used with the conventional relation for steady-state conduction in a spherical shell:

$$q = \frac{4\pi k_e r_i r_o \Delta T}{r_o - r_i}$$
 [7-62]

Equation (7-61) is valid for $0.25 \le \delta/r_i \le 1.5$ and

$$1.2 \times 10^2 < Gr \, Pr < 1.1 \times 10^9$$
 $0.7 < Pr < 4150$

Properties are evaluated at a volume mean temperature T_m defined by

$$T_m = \frac{(r_m^3 - r_i^3)T_i + (r_o^3 - r_m^3)T_o}{r_o^3 - r_i^3}$$
 [7-63]

where $r_m = (r_i + r_o)/2$. Equation (7-61) may also be used for eccentric spheres with a coordinate transformation as described in Reference 43.

Experimental results for free convection in enclosures are not always in agreement, but we can express them in a general form as

$$\frac{k_e}{k} = C(\operatorname{Gr}_{\delta} \operatorname{Pr})^n \left(\frac{L}{\delta}\right)^m$$
 [7-64]





7-11 Free Convection in Enclosed Spaces

Table 7-3 | Summary of empirical relations for free convection in enclosures in the form of Equation (7-61), correlation constants adjusted by Holman [74].

Fluid	Geometry	Gr _δ Pr	Pr	$\frac{L}{\delta}$	С	n	m	Reference(s)
C	Vti11t-	< 2000	L /L 10	<u> </u>				(7.55.50
Gas	Vertical plate,		$k_e/k = 1.0$	11 42	0.107	1	1	6, 7, 55, 59
	isothermal	6000–200,000	0.5–2	11–42	0.197	$\frac{1}{4}$	$-\frac{1}{9}$	
		$200,000-1.1 \times 10^7$	0.5-2	11-42	0.073	$\frac{1}{3}$	$-\frac{1}{9}$	
	Horizontal plate,	< 1700	$k_e/k = 1.0$					
	isothermal	1700-7000	0.5-2	_	0.059	0.4	0	6, 7, 55, 59, 62, 63
	heated from							
	below	$7000-3.2 \times 10^5$	0.5-2	_	0.212	$\frac{1}{4}$	0	66
		$> 3.2 \times 10^5$	0.5–2	_	0.061	$\frac{1}{3}$	0	
Liquid	Vertical plate,	< 2000	$k_e/k = 1.0$					
•	constant heat	$10^4 - 10^7$	1-20,000	10-40	Eq. 7-52	_	_	18, 61
	flux or isothermal	$10^6 - 10^9$	1-20	1-40	0.046	$\frac{1}{3}$	0	
	Horizontal plate,	< 1700	$k_e/k = 1.0$	_		3		7, 8, 58, 63, 66
	isothermal,	1700-6000	1-5000	_	0.012	0.6	0	
	heated from	6000-37,000	1-5000	_	0.375	0.2	0	
	below	$37,000-10^8$	1-20		0.13	0.3	0	
		$> 10^8$	1–20		0.057	$\frac{1}{3}$	0	
Gas or	Vertical annulus	Same as vertical						
liquid		plates						
-	Horizontal annulus,	6000–10 ⁶	1-5000	_	0.11	0.29	0	56, 57, 60
	isothermal	$10^6 - 10^8$	1-5000	_	0.40	0.20	0	•
	Spherical annulus	$120-1.1 \times 10^9$	0.7-4000	_	0.228	0.226	0	43

Table 7-3 lists values of the constants C, n, and m for a number of physical circumstances. These values may be used for design purposes in the absence of specific data for the geometry or fluid being studied. We should remark that some of the data correlations represented by Table 7-3 have been artificially adjusted by Holman [74] to give the characteristic exponents of $\frac{1}{4}$ and $\frac{1}{3}$ for the laminar and turbulent regimes of free convection. However, it appears that the error introduced by this adjustment is not significantly greater than the disagreement between different experimental investigations. The interested reader may wish to consult the specific references for more details.

For the annulus space the heat transfer is based on

$$q = \frac{2\pi k_e L \Delta T}{\ln(r_o/r_i)}$$
 [7-65]

where L is the length of the annulus and the gap spacing is $\delta = r_o - r_i$.

Extensive correlations for free convection between cylindrical, cubical, and spherical bodies and various enclosure geometries are given by Warrington and Powe [80]. The correlations cover a wide range of fluids.

Free convection through vertical plane layers of nonnewtonian fluids is discussed in Reference 38, but the results are too complicated to present here.

In the absence of more specific design information, the heat transfer for inclined enclosures may be calculated by substituting g' for g in the Grashof number, where

$$g' = g\cos\theta \tag{7-66}$$

and θ is the angle that the heater surface makes with the horizontal. This transformation may be expected to hold up to inclination angles of 60° and applies *only* to those cases





where the hotter surface is facing upward. Further information is available from Hollands et al. [66, 67, 69, 82].

Radiation R-Value for a Gap

As we have seen in conduction heat transfer, radiation boundary conditions may play an important role in the overall heat-transfer problem. This is particularly true in free-convection situations because free-convection heat-transfer rates are typically small. We will show in Section 8-7, Equation (8-42), that the radiant transfer across a gap separating two large parallel planes may be calculated with

$$q/A = \frac{\sigma \left(T_1^4 - T_2^4\right)}{1/\epsilon_1 + 1/\epsilon_2 - 1}$$
 [7-67]

where the temperatures are in degrees Kelvin and the ϵ 's are the respective emissivities of the surfaces. Using the concept of the *R*-value discussed in Section 2-3, we could write

$$(q/A)_{\rm rad} = \Delta T/R_{\rm rad}$$

and thus could determine an *R*-value for the radiation heat transfer in conjunction with Equation (7-67). That value would be strongly temperature-dependent and would operate in parallel with the *R*-value for the convection across the space, which could be obtained from

$$(q/A)_{\text{conv}} = k_e \Delta T/\delta = \Delta T/R_{\text{conv}}$$

so that

$$R_{\rm conv} = \delta/k_e$$

The total R-value for the combined radiation and convection across the space would be written as

$$R_{\text{tot}} = \frac{1}{1/R_{\text{rad}} + 1/R_{\text{conv}}}$$

The concept of combined radiation and convection in confined spaces is important in building applications.

Heat Transfer Across Vertical Air Gap

EXAMPLE 7-8

Air at atmospheric pressure is contained between two 0.5-m-square vertical plates separated by a distance of 15 mm. The temperatures of the plates are 100 and 40°C, respectively. Calculate the free-convection heat transfer across the air space. Also calculate the radiation heat transfer across the air space if both surfaces have $\epsilon = 0.2$.

■ Solution

We evaluate the air properties at the mean temperature between the two plates:

$$T_f = \frac{100 + 40}{2} = 70^{\circ}\text{C} = 343 \text{ K}$$

$$\rho = \frac{p}{RT} = \frac{1.0132 \times 10^5}{(287)(343)} = 1.029 \text{ kg/m}^3$$

$$\beta = \frac{1}{T_f} = \frac{1}{343} = 2.915 \times 10^{-3} \text{ K}^{-1}$$

$$\mu = 2.043 \times 10^{-5} \text{ kg/m} \cdot \text{s} \qquad k = 0.0295 \text{ W/m} \cdot ^{\circ}\text{C} \qquad \text{Pr} = 0.7$$





7-11 Free Convection in Enclosed Spaces

The Grashof-Prandtl number product is now calculated as

$$Gr_{\delta} Pr = \frac{(9.8)(1.029)^{2}(2.915 \times 10^{-3})(100 - 40)(15 \times 10^{-3})^{3}}{(2.043 \times 10^{-5})^{2}} 0.7$$

$$= 1.027 \times 10^{4}$$

We may now use Equation (7-64) to calculate the effective thermal conductivity, with L=0.5 m, $\delta=0.015$ m, and the constants taken from Table 7-3:

$$\frac{k_e}{k} = (0.197)(1.027 \times 10^4)^{1/4} \left(\frac{0.5}{0.015}\right)^{-1/9} = 1.343$$

The heat transfer may now be calculated with Equation (7-54). The area is $(0.5)^2 = 0.25 \text{ m}^2$, so that

$$q = \frac{(1.343)(0.0295)(0.25)(100 - 40)}{0.015} = 39.62 \text{ W}$$
 [135.2 Btu/h]

The radiation heat flux is calculated with Equation (7-67), taking $T_1=373$ K, $T_2=313$ K, and $\epsilon_1=\epsilon_2=0.2$. Thus, with $\sigma=5.669\times 10^{-8}$ W/m $^2\cdot K^4$,

$$(q/A)_{\text{rad}} = \frac{(5.669 \times 10^{-8})(373^4 - 313^4)}{[1/0.2 + 1/0.2 - 1]} = 61.47 \text{ W/m}^2$$

and

$$q_{\text{rad}} = (0.5)^2 (61.47) = 15.37 \text{ W}$$

or about half the value of the convection transfer across the space. Further calculation would show that for a smaller value of $\epsilon=0.05$, the radiation transfer is reduced to 3.55 W or, for a larger value of $\epsilon=0.8$, the transfer is 92.2 W. In any event, radiation heat transfer can be an important factor in such problems.

EXAMPLE 7-9

Heat Transfer Across Horizontal Air Gap

Two horizontal plates 20 cm on a side are separated by a distance of 1 cm with air at 1 atm in the space. The temperatures of the plates are 100° C for the lower and 40° C for the upper plate. Calculate the heat transfer across the air space.

■ Solution

The properties are the same as given in Example 7-8:

$$\rho = 1.029 \text{ kg/m}^3$$
 $\beta = 2.915 \times 10^{-3} \text{ K}^{-1}$
 $\mu = 2.043 \times 10^{-5} \text{ kg/m} \cdot \text{s}$ $k = 0.0295 \text{ W/m} \cdot ^{\circ}\text{C}$
 $Pr = 0.7$

The Gr Pr product is evaluated on the basis of the separating distance, so we have


Gr Pr =
$$\frac{(9.8)(1.029)^2(2.915 \times 10^{-3})(100 - 40)(0.01)^3}{(2.043 \times 10^{-5})^2}(0.7) = 3043$$

Consulting Table 7-3, we find C = 0.059, n = 0.4, and m = 0 so that

$$\frac{k_e}{k} = (0.059)(3043)^{0.4} \left(\frac{0.2}{0.01}\right)^0 = 1.46$$

and

$$q = \frac{k_{\mathcal{E}}A(T_1 - T_2)}{\delta} = \frac{(1.460)(0.0295)(0.2)^2(100 - 40)}{0.01} = 10.34 \text{ W}$$







EXAMPLE 7-10

Two 50-cm horizontal square plates are separated by a distance of 1 cm. The lower plate is maintained at a constant temperature of $100^{\circ}F$ and the upper plate is constant at $80^{\circ}F$. Water at atmospheric pressure occupies the space between the plates. Calculate the heat lost by the lower plate.

■ Solution

We evaluate properties at the mean temperature of 90°F and obtain, for water,

$$k = 0.623 \text{ W/m} \cdot {}^{\circ}\text{C}$$
 $\frac{g\beta\rho^2c_p}{\mu k} = 2.48 \times 10^{10}$

The Grashof-Prandtl number product is now evaluated using the plate spacing of 1 cm as the characteristic dimension.

Gr Pr =
$$(2.48 \times 10^{10})(0.01)^3(100 - 80)(5/9) = 2.76 \times 10^5$$

Now, using Equation (7-64) and consulting Table 7-3 we obtain

$$C = 0.13$$
 $n = 0.3$ $m = 0$

Therefore, Equation (7-64) becomes

$$\frac{k_e}{k} = (0.13)(2.76 \times 10^5)^{0.3} = 5.57$$

The effective thermal conductivity is thus

$$k_e = (0.623)(5.57) = 3.47 \text{ W/m} \cdot ^{\circ}\text{C}$$

and the heat transfer is

$$q = k_e A \Delta T / \delta = \frac{(3.47)(0.5)^2 (100 - 80)(5/9)}{0.01} = 964 \text{ W}$$

We see, of course, that the heat transfer across a water gap is considerably larger than for an air gap [Example 7-9] because of the larger thermal conductivity.

Reduction of Convection in Air Gap

EXAMPLE 7-11

A vertical air gap between two glass plates is to be evacuated so that the convective currents are essentially eliminated, that is, the air behaves as a pure conductor. For air at a mean temperature of $300 \, \text{K}$ and a temperature difference of $20 \, ^{\circ} \text{C}$, calculate the vacuum necessary for glass spacings of 1 and 2 cm.

Solution

Consulting Table 7-3, we find that for gases, a value of Gr_{δ} Pr < 2000 is necessary to reduce the system to one of pure conduction. At 300 K the propertiues of air are

$$k = 0.02624 \text{ W/m} \cdot {}^{\circ}\text{C}$$
 Pr = 0.7 $\mu = 1.846 \times 10^{-5} \text{ kg/m} \cdot \text{s}$ $\beta = 1/300$

and

$$\rho = p/RT = p/(287)(300)$$

We have

Gr_δ Pr =
$$g\beta\rho^2\Delta T\delta^3$$
Pr/ μ^2 = 2000
= $(9.8)(1/300)[p/(287)(300)]^2(20)\delta^3(0.7)/(1.846 \times 10^{-5})^2$





7-11 Free Convection in Enclosed Spaces

and $p^2\delta^3 = 7773$. Therefore, for a plate spacing of $\delta = 1$ cm we have

$$p = [7773/(0.01)^3]^{1/2} = 88200 \text{ Pa}$$

or, vacuum = $p_{\text{atm}} - p = 101320 - 88200 = 13120 \text{ Pa}$. For a spacing of 2 cm,

$$p = 31190 \text{ Pa}$$
 and vacuum = 70130 Pa

Both vacuum figures are modest and easily achieved in practice.

Evacuated (Low-Density) Spaces

In the equations presented for free convection in enclosures we have seen that when the product Gr_{δ} Pr is sufficiently small, usually less than about 2000, the fluid layer behaves as if pure conduction were involved and $k_e/k \to 1.0$. This means that the free-convection flow velocities are small. A small value of Gr_{δ} can result from either lowering the fluid pressure (density) or by reducing the spacing δ . If the pressure of a gas is reduced sufficiently, we refer to the situation as a low-density problem, which is influenced by the mean free path of the molecules and by individual molecular impacts.

A number of practical situations involve heat transfer between a solid surface and a low-density gas. In employing the term *low density*, we shall mean those circumstances where the mean free path of the gas molecules is no longer small in comparison with a characteristic dimension of the heat-transfer surface. The *mean free path* λ is the distance a molecule travels, on the average, between collisions. The larger this distance becomes, the greater the distance required to communicate the temperature of a hot surface to a gas in contact with it. This means that we shall not necessarily be able to assume that a gas in the immediate neighborhood of the surface will have the same temperature as the heated surface, as was done in the boundary-layer analyses. Evidently, the parameter that is of principal interest is a ratio of the mean free path to a characteristic body dimension. This grouping is called the Knudsen number,

$$Kn = \frac{\lambda}{L}$$
 [7-68]

According to the kinetic theory of gases, the mean free path may be calculated from

$$\lambda = \frac{0.707}{4\pi r^2 n} \tag{7-69}$$

where r is the effective molecular radius for collisions and n is the molecular density. An approximate relation for the mean free path of air molecules is given by

$$\lambda = 2.27 \times 10^{-5} \frac{T}{p}$$
 meters [7-70]


where T is in degrees Kelvin and p is in pascals.

As a first example of low-density heat transfer let us consider the two parallel infinite plates shown in Figure 7-11. The plates are maintained at different temperatures and separated by a gaseous medium. Let us first consider a case where the density or plate spacing is low enough that free convection effects are negligible, but with a gas density sufficiently high so that $\lambda \to 0$ and a linear temperature profile through the gas will be





Figure 7-11 | Effect of mean free path on conduction heat transfer between parallel plates: (a) physical model; (b) anticipated temperature profiles.



(b)

experienced, as shown for the case of λ_1 . As the gas density is lowered, the larger mean free paths require a greater distance from the heat-transfer surfaces in order for the gas to accommodate to the surface temperatures. The anticipated temperature profiles are shown in Figure 7-11b. Extrapolating the straight portion of the low-density curves to the wall produces a temperature "jump" ΔT , which may be calculated by making the following energy balance:

$$\frac{q}{A} = k \frac{T_1 - T_2}{g + L + g} = k \frac{\Delta T}{g}$$
 [7-71]

In this equation we are assuming that the extrapolation distance g is the same for both plate surfaces. In general, the temperature jump will depend on the type of surface, and these extrapolation distances will not be equal unless the materials are identical. For different types of materials we should have





7-11 Free Convection in Enclosed Spaces

$$\frac{q}{A} = k \frac{T_1 - T_2}{g_1 + L + g_2} = k \frac{\Delta T_1}{g_1} = k \frac{\Delta T_2}{g_2}$$
 [7-72]

where now ΔT_1 and ΔT_2 are the temperature jumps at the two heat-transfer surfaces and g_1 and g_2 are the corresponding extrapolation distances. For identical surfaces the temperature jump would then be expressed as

$$\Delta T = \frac{g}{2g + L} (T_1 - T_2)$$
 [7-73]

Similar expressions may be developed for low-density conduction between concentric cylinders. In order to predict the heat-transfer rate it is necessary to establish relations for the temperature jump for various gas-to-solid interfaces.

We have already mentioned that the temperature-jump effect arises as a result of the failure of the molecules to "accommodate" to the surface temperature when the mean free path becomes of the order of a characteristic body dimension. The parameter that describes this behavior is called the *accommodation coefficient* α , defined by

$$\alpha = \frac{E_i - E_r}{E_i - E_w} \tag{7-74}$$

where

 E_i = energy of incident molecules on a surface

 E_r = energy of molecules reflected from the surface

 E_w = energy molecules would have if they acquired energy of wall at temperature T_w

Values of the accommodation coefficient must be determined from experiment, and some typical values are given in Table 7-4.

It is possible to employ the kinetic theory of gases along with values of α to determine the temperature jump at a surface. The result of such an analysis is

$$T_{y=0} - T_w = \frac{2 - \alpha}{\alpha} \frac{2\gamma}{\gamma + 1} \frac{\lambda}{\Pr} \left. \frac{\partial T}{\partial y} \right|_{y=0}$$
 [7-75]


Table 7-4 | Thermal accommodation coefficients for air at low pressure in contact with various surfaces

Surface	Accommodation coefficient, $lpha$
Flat black lacquer on bronze	0.88-0.89
Bronze, polished	0.91 - 0.94
Machined	0.89-0.93
Etched	0.93-0.95
Cast iron, polished	0.87 - 0.93
Machined	0.87 - 0.88
Etched	0.89 - 0.96
Aluminum, polished	0.87 - 0.95
Machined	0.95 - 0.97
Etched	0.89 - 0.97





Figure 7-12 | Nomenclature for use with Equation (7-75).



The nomenclature for Equation (7-75) is noted in Figure 7-12. This temperature jump is denoted by ΔT in Figure 7-11, and the temperature gradient for use with Figure 7-11 would be

$$\frac{T_1 - T_2 - 2\Delta T}{L}$$

For very low densities (high vacuum) the mean free path may become very large compared to the plate separation distance and the conduction-convection heat transfer will approach zero. The reader should recognize, however, that the total heat transfer across the gap-space will be the sum of conduction-convection and radiation heat transfer. We will discuss radiation heat transfer in detail in Chapter 8, but we have already provided the relation in Equation (7-67) for calculation of radiant heat transfer between two parallel plates. We note that ϵ approaches 1.0 for highly absorptive surfaces and has a small value for highly reflective surfaces. Example 7-12 illustrates the application of the low-density relations to calculation of heat transfer across a gap.

Heat Transfer Across Evacuated Space

EXAMPLE 7-12

Two polished-aluminum plates (ϵ = 0.06) are separated by a distance of 2.5 cm in air at a pressure of 10^{-6} atm. The plates are maintained at 100 and 30°C, respectively. Calculate the conduction heat transfer through the air gap. Compare this with the radiation heat transfer and the conduction for air at normal atmospheric pressure.

■ Solution

We first calculate the mean free path to determine if low-density effects are important. From Equation (7-70), at an average temperature of $65^{\circ}C = 338 \text{ K}$,

$$\lambda = \frac{(2.27 \times 10^{-5})(338)}{(1.0132 \times 10^{+5})(10^{-6})} = 0.0757 \text{ m} = 7.57 \text{ cm} \quad [0.248 \text{ ft}]$$

Since the plate spacing is only 2.5 cm, we should expect low-density effects to be important. Evaluating properties at the mean air temperature of 65°C, we have

$$k = 0.0291 \text{ W/m} \cdot ^{\circ}\text{C} \quad [0.0168 \text{ Btu/h} \cdot \text{ft} \cdot ^{\circ}\text{F}]$$

$$\gamma = 1.40$$
 Pr = 0.7 $\alpha \approx 0.9$ from Table 7-4

Combining Equation (7-75) with the central-temperature-gradient relation gives

$$\Delta T = \frac{2 - \alpha}{\alpha} \frac{2\gamma}{\gamma + 1} \frac{\lambda}{\Pr} \frac{T_1 - T_2 - 2\Delta T}{L}$$





7-12 Combined Free and Forced Convection

Inserting the appropriate properties gives

$$\Delta T = \frac{2 - 0.9}{0.9} \frac{2.8}{2.4} \frac{0.0757}{0.7} \frac{100 - 30 - 2\Delta T}{0.025}$$
$$= 32.38^{\circ} \text{C} \qquad [58.3^{\circ}\text{F}]$$

The conduction heat transfer is thus

$$\frac{q}{A} = k \frac{T_1 - T_2 - 2\Delta T}{L} = \frac{(0.0291)(70 - 64.76)}{0.025}$$
$$= 6.099 \text{ W/m}^2 \quad [1.93 \text{ Btu/h} \cdot \text{ft}^2]$$

At normal atmospheric pressure the conduction would be

$$\frac{q}{A} = k \frac{T_1 - T_2}{I} = 81.48 \text{ W/m}^2 \quad [25.8 \text{ Btu/h} \cdot \text{ft}^2]$$

The radiation heat transfer is calculated with Equation (8-42), taking $\epsilon_1 = \epsilon_2 = 0.06$ for polished aluminum:

$$\left(\frac{q}{A}\right)_{\text{rad}} = \frac{\sigma(T_1^4 - T_2^4)}{2/\epsilon - 1} = \frac{(5.669 \times 10^{-8})(393^4 - 303^4)}{2/0.06 - 1}$$
$$= 27.05 \text{ W/m}^2 \quad [8.57 \text{ Btu/h} \cdot \text{ft}^2]$$

Thus, at the low-density condition the radiation heat transfer is almost 5 times as large as the conduction, even with highly polished surfaces.

7-12 | COMBINED FREE AND FORCED CONVECTION

A number of practical situations involve convection heat transfer that is neither "forced" nor "free" in nature. The circumstances arise when a fluid is forced over a heated surface at a rather low velocity. Coupled with the forced-flow velocity is a convective velocity that is generated by the buoyancy forces resulting from a reduction in fluid density near the heated surface.

A summary of combined free- and forced-convection effects in tubes has been given by Metais and Eckert [10], and Figure 7-13 presents the regimes for combined convection in vertical tubes. Two different combinations are indicated in this figure. *Aiding flow* means that the forced- and free-convection currents are in the same direction, while *opposing flow* means that they are in the opposite direction. The abbreviation UWT means uniform wall temperature, and the abbreviation UHF indicates data for uniform heat flux. It is fairly easy to anticipate the qualitative results of the figure. A large Reynolds number implies a large forced-flow velocity, and hence less influence of free-convection currents. The larger the value of the Grashof-Prandtl product, the more one would expect free-convection effects to prevail.

Figure 7-14 presents the regimes for combined convection in horizontal tubes. In this figure the Graetz number is defined as

$$Gz = \operatorname{Re} \operatorname{Pr} \frac{d}{L}$$
 [7-76]


The applicable range of Figures 7-13 and 7-14 is for

$$10^{-2} < \Pr\left(\frac{d}{L}\right) < 1$$





Figure 7-13 | Regimes of free, forced, and mixed convection for flow through vertical tubes, according to Reference 10.



The correlations presented in the figures are for constant wall temperature. All properties are evaluated at the film temperature.

Brown and Gauvin [17] have developed a better correlation for the mixed-convection, laminar flow region of Figure 7-14:

Nu = 1.75
$$\left(\frac{\mu_b}{\mu_w}\right)^{0.14} [Gz + 0.012(Gz Gr^{1/3})^{4/3}]^{1/3}$$
 [7-77]

where μ_b is evaluated at the bulk temperature. This relation is preferred over that shown in Figure 7-14. Further information is available in Reference 68. The problem of combined free and forced convection from horizontal cylinders is treated in detail by Fand and Keswani [47].

Criterion for Free or Forced Convection


The general notion that is applied in combined-convection analysis is that the predominance of a heat-transfer mode is governed by the fluid velocity associated with that mode. A forced-convection situation involving a fluid velocity of 30 m/s, for example, would be expected to overshadow most free-convection effects encountered in ordinary gravitational fields because the velocities of the free-convection currents are small in comparison with





7-12 Combined Free and Forced Convection

Figure 7-14 | Regimes of free, forced, and mixed convection for flow through horizontal tubes, according to Metais and Eckert [10].



30 m/s. On the other hand, a forced-flow situation at very low velocities ($\sim 0.3 \text{ m/s}$) might be influenced appreciably by free-convection currents. An order-of-magnitude analysis of the free-convection boundary-layer equations will indicate a general criterion for determining whether free-convection effects dominate. The criterion is that when

$$Gr/Re^2 > 10$$
 [7-78]

free convection is of primary importance. This result is in agreement with Figures 7-13 and 7-14.

EXAMPLE 7-13

Combined Free and Forced Convection with Air

Air at 1 atm and 27° C is forced through a horizontal 25-mm-diameter tube at an average velocity of 30 cm/s. The tube wall is maintained at a constant temperature of 140° C. Calculate the heat-transfer coefficient for this situation if the tube is 0.4 m long.

■ Solution

For this calculation we evaluate properties at the film temperature:

$$T_f = \frac{140 + 27}{2} = 83.5$$
°C = 356.5 K





$$\begin{split} \rho_f &= \frac{p}{RT} = \frac{1.0132 \times 10^5}{(287)(356.5)} = 0.99 \text{ kg/m}^3 \\ \beta &= \frac{1}{T_f} = 2.805 \times 10^{-3} \text{ K}^{-1} \qquad \mu_w = 2.337 \times 10^{-5} \text{ kg/m} \cdot \text{s} \\ \mu_f &= 2.102 \times 10^{-5} \text{ kg/m} \cdot \text{s} \qquad k_f = 0.0305 \text{ W/m} \cdot ^{\circ}\text{C} \qquad \text{Pr} = 0.695 \end{split}$$

Let us take the bulk temperature as 27°C for evaluating μ_b ; then

$$\mu_b = 1.8462 \times 10^{-5} \text{ kg/m} \cdot \text{s}$$

The significant parameters are calculated as

$$\begin{split} \mathrm{Re}_f &= \frac{\rho u d}{\mu} = \frac{(0.99)(0.3)(0.025)}{2.102 \times 10^{-5}} = 3.53 \\ \mathrm{Gr} &= \frac{\rho^2 g \beta (T_w - T_b) d^3}{\mu^2} = \frac{(0.99)^2 (9.8)(2.805 \times 10^{-3})(140 - 27)(0.025)^3}{(2.102 \times 10^{-5})^2} \\ &= 1.007 \times 10^5 \\ \mathrm{Gr} \, \mathrm{Pr} \frac{d}{L} &= (1.077 \times 10^5)(0.695) \frac{0.025}{0.4} = 4677 \end{split}$$

According to Figure 7-14, the mixed-convection-flow regime is encountered. Thus we must use Equation (7-77). The Graetz number is calculated as

Gz = Re Pr
$$\frac{d}{L} = \frac{(353)(0.695)(0.025)}{0.4} = 15.33$$

and the numerical calculation for Equation (7-77) becomes

Nu = 1.75
$$\left(\frac{1.8462}{2.337}\right)^{0.14} \{15.33 + (0.012)[(15.33)(1.077 \times 10^5)^{1/3}]^{4/3}\}^{1/3}$$

= 7.70

The average heat-transfer coefficient is then calculated as

$$\overline{h} = \frac{k}{d}$$
Nu = $\frac{(0.0305)(7.70)}{0.025}$ = 9.40 W/m² · °C [1.67 Btu/h · ft² · °F]

It is interesting to compare this value with that which would be obtained for strictly laminar forced convection. The Sieder-Tate relation [Equation (6-10)] applies, so that

Nu = 1.86(Re Pr)^{1/3}
$$\left(\frac{\mu_f}{\mu_w}\right)^{0.14} \left(\frac{d}{L}\right)^{1/3}$$

= 1.86 Gz^{1/3} $\left(\frac{\mu_f}{\mu_w}\right)^{0.14}$
= (1.86)(15.33)^{1/3} $\left(\frac{2.102}{2.337}\right)^{0.14}$

and

$$\overline{h} = \frac{(4.55)(0.0305)}{0.025} = 5.55 \text{ W/m}^2 \cdot ^{\circ}\text{C} \quad [0.977 \text{ Btu/h} \cdot \text{ft}^2 \cdot ^{\circ}\text{F}]$$

Thus there would be an error of -41 percent if the calculation were made strictly on the basis of laminar forced convection.





7-14 Summary Procedure for All Convection Problems

Table 7-5 | Summary of free-convection heat-transfer relations T. For most cases, properties are evaluated at $T_f = (T_w + T_\infty)/2$.

Geometry	Equation	Restrictions	Equation number
A variety of isothermal surfaces	$Nu_f = C(Gr_f Pr_f)^m$ C and m from Table 7-1	See Table 7-1	(7-25)
Vertical isothermal surface	$\overline{\mathrm{Nu}}^{1/2} = 0.825 + \frac{0.387 \text{ Ra}^{1/6}}{[1 + (0.492/\mathrm{Pr})^{9/16}]^{8/27}}$	$10^{-1} < \text{Ra}_L < 10^{12}$ Also see Fig. 7-5	(7-29)
Vertical surface, constant	$Nu_{xf} = C(Gr_x^* Pr_f)^m$	$C = 0.60, m = \frac{1}{5} \text{ for } 10^5 < \text{Gr}_x^* \text{Pr} < 10^{11}$	(7-31)
heat flux, local h		$C = 0.17, m = \frac{1}{4} \text{ for } 2 \times 10^{13} < \text{Gr}^*\text{Pr} < 10^{16}$	(7-32)
Isothermal horizontal cylinders	$\overline{\text{Nu}}^{1/2} = 0.60 + 0.387 \left\{ \frac{\text{Gr Pr}}{[1 + (0.559/\text{Pr})^{9/16}]^{16/9}} \right\}^{1/6}$	$10^{-5} < Gr Pr < 10^{13}$ Also see Fig. 7-6	(7-36)
Horizontal surface, constant heat flux		See text	(7-39) to (7-42)
Inclined surfaces	Section 7-7	See text	
Spheres	$\begin{aligned} Nu &= 2 + 0.43 (Gr \ Pr)^{1/4} \\ Nu &= 2 + 0.5 (Gr \ Pr)^{1/4} \\ Nu &= 2 + \frac{0.589 (Gr \ Pr)^{1/4}}{[1 + (0.469/Pr)^{9/16}]^{4/9}} \end{aligned}$	$1 < Gr Pr < 10^{5}$ water, $3 \times 10^{5} < Gr Pr < 8 \times 10^{8}$ $0.5 < Pr$ $Gr Pr < 10^{11}$	(7-50) (7-51) (7-52)
Enclosed spaces	$q = k_e A (\Delta T/\delta)$ $\frac{k_e}{k} = C (\operatorname{Gr}_{\delta} \operatorname{Pr})^n (L/\delta)^m$	Constants C , m , and n from Table 7-3 Pure conduction for $Gr_{\delta} Pr < 2000$	(7-57) (7-64)
Across evacuated spaces	Most transfer is by radiation		

7-13 | SUMMARY

By now the reader will have sensed that there is an abundance of empirical relations for natural convection systems. Our purposes in this section are to (1) issue a few words of caution and (2) provide a convenient table to summarize the relations.

Most free-convection data are collected under laboratory conditions in still air, still water, etc. A practical free-convection problem might not be so fortunate and the boundary layer could have a slightly added forced-convection effect. In addition, real surfaces in practice are seldom isothermal or constant heat flux so the correlations developed from laboratory data for these conditions may not strictly apply. The net result, of course, is that the engineer must realize that calculated values of the heat-transfer coefficient can vary \pm 25 percent from what will actually be experienced.

For solution of free-convection problems one should follow a procedure similar to that given in Chapter 6 for forced-convection problems. To aid the reader, a summary of free-convection correlations is given in Table 7-5.

7-14 | SUMMARY PROCEDURE FOR ALL CONVECTION PROBLEMS

At the close of Chapter 6 we gave a brief procedure for calculation of convection heat transfer. We now are in a position to expand that discussion to include the possibility of free-convection exchange. The procedure is as follows:

1. Specify the fluid involved and be prepared to determine properties of that fluid. This may seem like a trivial step, but a surprisingly large number of errors are made in practice by choosing the *wrong* fluid, that is to say, air instead of water.





- 2. Specify the geometry of the problem. Again, a seemingly simple matter, but important. Is there flow *inside* a tube, or flow *across the outside* of a tube, or flow *along the length* of a tube? Is the flow internal or external?
- 3. Decide whether the problem involves free convection or forced convection. If there is no specification of forcing the fluid through a channel or across some heated surface, free convection may be presumed. If there is a clear specification of a flow velocity, or mass flow rate, then forced convection may be assumed. When very small forced velocities are involved, combination free convection—forced convection may be encountered and the relative magnitudes of Re and Gr may need to be examined.
- 4. Once steps 1–3 are accomplished, decide on a temperature for evaluating fluid properties. This will usually be some average bulk temperature for forced flow in channels, and a film temperature $T_f = (T_\infty + T_{\rm surface})/2$ for either free or forced-convection flow over exterior surfaces. Some modification of this calculation may be needed once the final convection relation for h is determined.
- 5. Determine the flow regime by evaluating the Grashof-Prandtl number product for free-convection problems or the Reynolds number for forced-convection situations. *Be particularly careful to employ the correct characteristic body dimension in this calculation.* A large number of mistakes are made in practice by failing to make this calculation properly, in accordance with the findings of step 2 above. At this point, determine if an average or local heat-transfer coefficient is required in the problem. Revise the calculation of Gr Pr or Re as needed.
- **6.** Select an appropriate correlation equation for *h* in terms of the findings above. Be sure the equation fits the flow situation and geometry of the problem. If the equation selected requires modification of temperature-property determinations, revise the calculations in steps 4 and 5.
- 7. Calculate the value of h needed for the problem. Again, check to be sure that the calculation matches the geometry, fluid, type of flow, and flow regime for the problem.
- **8.** Determine convection heat transfer for the problem, which is usually calculated with an equation of the form

$$q = h A_{\text{surface}} (T_{\text{surface}} - T_{\text{free stream}})$$

for either free or forced convection over exterior surfaces, and

$$q = h A_{\text{surface}} (T_{\text{surface}} - T_{\text{bulk}})$$

for forced convection inside channels. Be careful to employ the correct value for $A_{\rm surface}$, which is the *surface area in contact with the fluid for which h is calculated.* For forced convection inside a tube, $A_{\rm surface}$ is $\pi d_i L$ (not the flow cross-sectional area $\pi d_i^2/4$), while for crossflow or free convection on the outside of a tube, $A_{\rm surface}$ is $\pi d_o L$. The surface area for complicated fin arrangements like those illustrated in Figure 2-14 would be the total fin(s) surface area in contact with the surrounding fluid (presumably air). This procedure is summarized in Figure 7-15, which also appears in the inside back cover.


REVIEW QUESTIONS

- 1. Why is an analytical solution of a free-convection problem more involved than its forced-convection counterpart?
- 2. Define the Grashof number. What is its physical significance?





Figure 7-15 | Summary of convection calculation procedure.







- 3. What is the approximate criterion for transition to turbulence in a free-convection boundary layer?
- **4.** What functional form of equation is normally used for correlation of free-convection heat-transfer data?
- 5. Discuss the problem of combined free and forced convection.
- **6.** What is the approximate criterion dividing pure conduction and free convection in an enclosed space between vertical walls?
- **7.** How is a modified Grashof number defined for a constant-heat-flux condition on a vertical plate?

LIST OF WORKED EXAMPLES

- 7-1 Constant heat flux from vertical plate
- 7-2 Heat transfer from isothermal vertical plate
- 7-3 Heat transfer from horizontal tube in water
- 7-4 Heat transfer from fine wire in air
- 7-5 Heated horizontal pipe in air
- **7-6** Cube cooling in air
- 7-7 Calculation with simplified relations
- 7-8 Heat transfer across vertical air gap
- 7-9 Heat transfer across horizontal air gap
- 7-10 Heat transfer across water layer
- 7-11 Reduction of convection in air gap
- **7-12** Heat transfer across evacuated space
- 7-13 Combined free and forced convection with air

PROBLEMS

- 7-1 Suppose the heat-transfer coefficients for forced or free convection over vertical flat plates are to be compared. Develop an approximate relation between the Reynolds and Grashof numbers such that the heat-transfer coefficients for pure forced convection and pure free convection are equal. Assume laminar flow.
- **7-2** For a vertical isothermal flat plate at 93° C exposed to air at 20° C and 1 atm, plot the free-convection velocity profiles as a function of distance from the plate surface at x positions of 15, 30, and 45 cm.
- 7-3 Show that $\beta = 1/T$ for an ideal gas having the equation of state $p = \rho RT$.
- 7-4 A 1-ft-square vertical plate is maintained at 65°C and is exposed to atmospheric air at 15°C. Compare the free-convection heat transfer from this plate with that which would result from forcing air over the plate at a velocity equal to the maximum velocity that occurs in the free-convection boundary layer. Discuss this comparison.
- **7-5** A vertical flat plat maintained at 350 K is exposed to room air at 300 K and 1 atm. Estimate the plate height necessary to produce a free-convection boundary layer thickness of 2.0 cm.
- **7-6** Plot the free-convection boundary-layer thickness as a function of *x* for a vertical plate maintained at 80°C and exposed to air at atmospheric pressure and 15°C. Consider the laminar portion only.





- 7-7 Two vertical flat plates at 65°C are placed in a tank of water at 25°C. If the plates are 30 cm high, what is the minimum spacing that will prevent interference of the free-convection boundary layers?
- **7-8** A 2.0-cm-diameter cylinder is placed horizontally in a pool of water at 70°F. The surface of the cylinder is maintained at 130°F. Calculate the heat lost by the cylinder per meter of length.
- **7-9** A vertical cylinder having a length of 30 cm is maintained at 100°C and exposed to room air at 15°C. Calculate the minimum diameter the cylinder can have in order to behave as a vertical flat plate.
- **7-10** A 1-m-square vertical plate is heated to 300°C and placed in room air at 25°C. Calculate the heat loss from one side of the plate.
- 7-11 A vertical flat plate is maintained at a constant temperature of 120°F and exposed to atmospheric air at 70°F. At a distance of 14 in. from the leading edge of the plate the boundary layer thickness is 1.0 in. Estimate the thickness of the boundary layer at a distance of 24 in. from the leading edge.
- 7-12 Condensing steam at 1 atm is used to maintain a vertical plate 20 cm high and 3.0 m wide at a constant temperature of 100°C. The plate is exposed to room air at 20°C. What flow rate of air will result from this heating process? What is the total heating supplied to the room air?
- **7-13** A vertical flat plate 10 cm high and 1.0 m wide is maintained at a constant temperature of 310 K and submerged in a large pool of liquid water at 290 K. Calculate the free-convection heat lost by the plate and the free-convection flow rate induced by the heated plate.
- **7-14** A vertical cylinder 1.8 m high and 7.5 cm in diameter is maintained at a temperature of 93°C in an atmospheric environment of 30°C. Calculate the heat lost by free convection from this cylinder. For this calculation the cylinder may be treated as a vertical flat plate.
- **7-15** The outside wall of a building 6 m high receives an average radiant heat flux from the sun of 1100 W/m². Assuming that 95 W/m² is conducted through the wall, estimate the outside wall temperature. Assume the atmospheric air on the outside of the building is at 20°C.
- **7-16** Assuming that a human may be approximated by a vertical cylinder 30 cm in diameter and 2.0 m tall, estimate the free-convection heat loss for a surface temperature of 24°C in ambient air at 20°C.
- 7-17 A 30-cm-square vertical plate is heated electrically such that a constant-heat-flux condition is maintained with a total heat dissipation of 30 W. The ambient air is at 1 atm and 20°C. Calculate the value of the heat-transfer coefficient at heights of 15 and 30 cm. Also calculate the average heat-transfer coefficient for the plate.
- **7-18** A 0.3-m-square vertical plate is maintained at 55°C and exposed to room air at 1 atm and 20°C. Calculate the heat lost from *both* sides of the plate.
- **7-19** Calculate the free-convection heat loss from a 0.61-m-square vertical plate maintained at 100°C and exposed to helium at 20°C and a pressure of 2 atm.
- **7-20** A large vertical plate 6.1 m high and 1.22 m wide is maintained at a constant temperature of 57°C and exposed to atmospheric air at 4°C. Calculate the heat lost by the plate.
- **7-21** A 1-m-square vertical plate is maintained at 49°C and exposed to room air at 21°C. Calculate the heat lost by the plate.





- **7-22** What vertical distance is necessary to produce a Rayleigh number of 10^{12} in air at standard conditions and $\Delta T = 10^{\circ}\text{C}$?
- **7-23** A 25-by-25-cm vertical plate is fitted with an electric heater that produces a constant heat flux of 1000 W/m². The plate is submerged in water at 15°C. Calculate the heat-transfer coefficient and the average temperature of the plate. How much heat would be lost by an isothermal surface at this average temperature?
- **7-24** Assume that one-half of the heat transfer by free convection from a horizontal cylinder occurs on each side of the cylinder because of symmetry considerations. Going by this assumption, compare the heat transfer on each side of the cylinder with that from a vertical flat plate having a height equal to the circumferential distance from the bottom stagnation point to the top stagnation point on the cylinder. Discuss this comparison.
- 7-25 A horizontal cylindrical heater with d=2 cm is placed in a pool of sodium-potassium mixture with 22 percent sodium. The mixture is at 120° C, and the heater surface is constant at 200° C. Calculate the heat transfer for a heater 40 cm long.
- **7-26** A vertical flat plate 15 cm high and 50 cm wide is maintained at a constant temperature of 325 K and placed in a large tank of helium at a pressure of 2.2 atm and a temperature of 0°C. Calculate the heat lost by the plate and the free-convection flow rate induced.
- **7-27** A horizontal heating rod having a diameter of 3.0 cm and a length of 1 m is placed in a pool of saturated liquid ammonia at 20°C. The heater is maintained at a constant surface temperature of 70°C. Calculate the heat-transfer rate.
- **7-28** Condensing steam at 120°C is to be used inside a 7.5-cm-diameter horizontal pipe to provide heating for a certain work area where the ambient air temperature is 20°C. The total heating required is 29.3 kW. What length pipe would be required to accomplish this heating?
- **7-29** A 10-cm length of platinum wire 0.4 mm in diameter is placed horizontally in a container of water at 38°C and is electrically heated so that the surface temperature is maintained at 93°C. Calculate the heat lost by the wire.
- **7-30** Water at the rate of 0.8 kg/s at 90°C flows through a steel pipe with 2.5-cm ID and 3-cm OD. The outside surface temperature of the pipe is 85°C, and the temperature of the surrounding air is 20°C. The room pressure is 1 atm, and the pipe is 15 m long. How much heat is lost by free convection to the room?
- **7-31** A horizontal pipe 8.0 cm in diameter is located in a room where atmospheric air is at 25°C. The surface temperature of the pipe is 140°C. Calculate the free-convection heat loss per meter of pipe.
- **7-32** A horizontal 1.25-cm-OD tube is heated to a surface temperature of 250°C and exposed to air at room temperature of 20°C and 1 atm. What is the free-convection heat transfer per unit length of tube?
- **7-33** A horizontal electric heater 2.5 cm in diameter is submerged in a light-oil bath at 93°C. The heater surface temperature is maintained at 150°C. Calculate the heat lost per meter of length of the heater.
- **7-34** A 0.3-m-square air-conditioning duct carries air at a temperature such that the outside temperature of the duct is maintained at 15.6°C and is exposed to room air at 27°C. Estimate the heat gained by the duct per meter of length.
- **7-35** A fine wire having a diameter of 0.001 in (0.0254 mm) is heated by an electric current and placed horizontally in a chamber containing helium at 3 atm and 10°C. If the surface temperature of the wire is not to exceed 240°C, calculate the electric power to be supplied per unit length.





- **7-36** A heated horizontal cylinder having a surface temperature of 93°C, diameter of 10 cm, and length of 2.0 m is exposed to Helium at 1 atm and -18°C. Calculate the heat lost by the cylinder.
- 7-37 A large circular duct, 3.0 m in diameter, carries hot gases at 250°C. The outside of the duct is exposed to room air at 1 atm and 20°C. Estimate the heat loss per unit length of the duct.
- **7-38** A 2.0-cm-diameter cylinder is placed in a tank of glycerine at 20°C. The surface temperature of the heater is 60°C, and its length is 60 cm. Calculate the heat transfer.
- **7-39** A 3.5-cm-diameter cylinder contains an electric heater that maintains a constant heat flux at the surface of 1500 W/m². If the cylinder is inclined at an angle of 35° with the horizontal and exposed to room air at 20°C, estimate the average surface temperature.
- **7-40** A 30-cm-diameter horizontal pipe is maintained at a constant temperature of 25°C and placed in room air at 20°C. Calculate the free-convection heat loss from the pipe per unit length.
- **7-41** A 12.5 cm-diameter duct is maintained at a constant temperature of 260°C by hot combustion gases inside. The duct is located horizontally in a small warehouse area having an ambient temperature of 20°C. Calculate the length of the duct necessary to provide 37 kW of convection heating.
- **7-42** A horizontal cylinder with diameter of 5 cm and length of 3 m is maintained at 180°F and submerged in water that is at 60°F. Calculate the heat lost by the cylinder.
- **7-43** A 2.0-m-diameter horizontal cylinder is maintained at a constant temperature of 77°C and exposed to a large warehouse space at 27°C. The cylinder is 20 m long. Calculate the heat lost by the cylinder.
- **7-44** Calculate the rate of free-convection heat loss from a 30-cm-diameter sphere maintained at 90°C and exposed to atmospheric air at 20°C.
- **7-45** A 2.5-cm-diameter sphere at 35°C is submerged in water at 10°C. Calculate the rate of free-convection heat loss.
- **7-46** A spherical balloon gondola 2.4 m in diameter rises to an altitude where the ambient pressure is 1.4 kPa and the ambient temperature is -50° C. The outside surface of the sphere is at approximately 0° C. Estimate the free-convection heat loss from the outside of the sphere. How does this compare with the forced-convection loss from such a sphere with a low free-stream velocity of approximately 30 cm/s?
- **7-47** A 4.0-cm diameter sphere is maintained at 38°C and submerged in water at 15°C. Calculate the heat-transfer rate under these conditions.
- **7-48** Apply the reasoning pertaining to the last entry of Table 7-1 to free convection from a sphere and compare with Equation (7-50).
- **7-49** Using the information in Table 7-1 and the simplified relations of Table 7-2, devise a simplified relation that may be used as a substitute for Equation (7-50) to calculate free convection from a sphere to air at 1 atm.
- **7-50** A horizontal tube having a diameter of 30 cm is maintained at a constant temperature of 204°C and exposed to helium at 3 atm and 93°C. Calculate the heat lost from the tube for a tube length of 10.4 m. Express in units of watts.
- **7-51** A large bare duct having a diameter of 30 cm runs horizontally across a factory area having environmental conditions of 20°C and 1 atm. The length of the duct is 100 m. Inside the duct a low pressure steam flow maintains the duct wall temperature constant at 120°C. Calculate the total heat lost by convection from the duct to the room.





- **7-52** A circular hot plate, 15 cm in diameter, is maintained at 150°C in atmospheric air at 20°C. Calculate the free-convection heat loss when the plate is in a horizontal position.
- 7-53 An engine-oil heater consists of a large vessel with a square-plate electric-heater surface in the bottom of the vessel. The heater plate is 30 by 30 cm and is maintained at a constant temperature of 60°C. Calculate the heat-transfer rate for an oil temperature of 20°C.
- 7-54 Small electric strip heaters with a width of 6 mm are oriented in a horizontal position. The strips are maintained at 500°C and exposed to room air at 20°C. Assuming that the strips dissipate heat from both the top and the bottom surfaces, estimate the strip length required to dissipate 2 kW of heat by free convection.
- **7-55** The top surface of a 10-by-10-m horizontal plate is maintained at 25°C and exposed to room temperature at 28°C. Estimate the heat transfer.
- **7-56** A 4-by-4-m horizontal heater is placed in room air at 15°C. Both the top and the bottom surfaces are heated to 50°C. Estimate the total heat loss by free convection.
- **7-57** A horizontal plate, uniform in temperature at 400 K, has the shape of an equilateral triangle 45 cm on each side and is exposed to atmospheric air at 300 K. Estimate the heat lost by the plate.
- **7-58** A heated plate, 20 by 20 cm, is inclined at an angle of 60° with the horizontal and placed in water. Approximately constant-heat-flux conditions prevail with a mean plate temperature of 40°C and the heated surface facing downward. The water temperature is 20°C. Calculate the heat lost by the plate.
- **7-59** Repeat Problem 7-58 for the heated plate facing upward.
- **7-60** A double plate-glass window is constructed with a 1.25-cm air space. The plate dimensions are 1.2 by 1.8 m. Calculate the free-convection heat-transfer rate through the air space for a temperature difference of 30°C and $T_1 = 20$ °C.
- **7-61** A flat-plate solar collector is 1 m square and is inclined at an angle of 20° with the horizontal. The hot surface at 160°C is placed in an enclosure that is evacuated to a pressure of 0.1 atm. Above the hot surface, and parallel to it, is the transparent window that admits the radiant energy from the sun. The hot surface and window are separated by a distance of 8 cm. Because of convection to the surroundings, the window temperature is maintained at 40°C. Calculate the free-convection heat transfer between the hot surface and the transparent window.
- **7-62** A flat plate 1 by 1 m is inclined at 30° with the horizontal and exposed to atmospheric air at 30°C and 1 atm. The plate receives a net radiant-energy flux from the sun of 700 W/m², which then is dissipated to the surroundings by free convection. What average temperature will be attained by the plate?
- **7-63** A horizontal cylinder having a diameter of 5 cm and an emissivity of 0.5 is placed in a large room, the walls of which are maintained at 35°C. The cylinder loses heat by natural convection with an h of 6.5 W/m² ·°C. A sensitive thermocouple placed on the surface of the cylinder measures the temperature as 30°C. What is the temperature of the air in the room?
- **7-64** A 10-by-10-cm plate is maintained at 80°C and inclined at 45° with the horizontal. Calculate the heat loss from both sides of the plate to room air at 20°C.
- **7-65** A 5-by-5-cm plate is maintained at 50°C and inclined at 60° with the horizontal. Calculate the heat loss from both sides of the plate to water at 20°C.
- **7-66** Air at 1 atm and 38°C is forced through a horizontal 6.5-mm-diameter tube at an average velocity of 30 m/s. The tube wall is maintained at 540°C, and the tube

370 Problems



- is 30 cm long. Calculate the average heat-transfer coefficient. Repeat for a velocity of 30 m/s and a tube wall temperature of 800°C.
- **7-67** A small copper block having a square bottom 2.5 by 2.5 cm and a vertical height of 5 cm cools in room air at 1 atm and 15°C. The block is isothermal at 100°C. Calculate the heat-transfer rate.
- **7-68** A horizontal plate in the shape of an equilateral triangle 40 cm on a side is maintained at a constant temperature of 55°C and exposed to atmospheric air at 25°C. Calculate the heat lost by the top surface of the plate.
- **7-69** A small horizontal heater is in the shape of a circular disk with a diameter of 3 cm. The disk is maintained at 70°C and exposed to atmospheric air at 30°C. Calculate the heat loss.
- **7-70** A hot ceramic block at 400°C has dimensions of 15 by 15 by 8 cm high. It is exposed to room air at 27°C. Calculate the free-convection heat loss.
- 7-71 A magnetic amplifier is encased in a cubical box 15 cm on a side and must dissipate 50 W to surrounding air at 20°C. Estimate the surface temperature of the box
- 7-72 A glass thermometer is placed in a large room, the walls of which are maintained at 10°C. The convection coefficient between the thermometer and the room air is $5 \text{ W/m}^2 \cdot ^{\circ}\text{C}$, and the thermometer indicates a temperature of 30°C. Determine the temperature of the air in the room. Take $\epsilon = 1.0$.
- 7-73 A horizontal air-conditioning duct having a horizontal dimension of 30 cm and a vertical dimension of 15 cm is maintained at 45°C and exposed to atmospheric air at 20°C. Calculate the heat lost per unit length of duct.
- 7-74 Two 30-cm-square vertical plates are separated by a distance of 1.25 cm, and the space between them is filled with water. A constant-heat-flux condition is imposed on the plates such that the average temperature is 38°C for one and 60°C for the other. Calculate the heat-transfer rate under these conditions. Evaluate properties at the mean temperature.
- 7-75 An enclosure contains helium at a pressure of 1.3 atm and has two vertical heating surfaces, which are maintained at 80 and 20°C, respectively. The vertical surfaces are 40 by 40 cm and are separated by a gap of 2.0 cm. Calculate the free-convection heat transfer between the vertical surfaces.
- **7-76** A horizontal annulus with inside and outside diameters of 8 and 10 cm, respectively, contains liquid water. The inside and outside surfaces are maintained at 40 and 20°C, respectively. Calculate the heat transfer across the annulus space per meter of length.
- 7-77 Two concentric spheres are arranged to provide storage of brine inside the inner sphere at a temperature of -10° C. The inner-sphere diameter is 2 m, and the gap spacing is 5 cm. The outer sphere is maintained at 30°C, and the gap space is evacuated to a pressure of 0.05 atm. Estimate the free-convection heat transfer across the gap space.
- 7-78 A large vat used in food processing contains a hot oil at 400°F. Surrounding the vat on the vertical sides is a shell that is cooled to 140°F. The air space separating the vat and the shell is 35 cm high and 3 cm thick. Estimate the free-convection loss per square meter of surface area.
- **7-79** Two 30-cm-square vertical plates are separated by a distance of 2.5 cm and air at 1 atm. The two plates are maintained at temperatures of 200 and 90°C, respectively. Calculate the heat-transfer rate across the air space.





- **7-80** A horizontal air space is separated by a distance of 1.6 mm. Estimate the heat-transfer rate per unit area for a temperature difference of 165°C, with one plate temperature at 90°C.
- **7-81** Repeat Problem 7-80 for a horizontal space filled with water.
- **7-82** An atmospheric vertical air space 4.0 ft high has a temperature differential of 20° F at 300 K. Calculate and plot k_e/k and the R value for spacings of 0 to 10 in. At approximately what spacing is the R value a maximum?
- **7-83** Two vertical plates 50 by 50 cm are separated by a space of 4 cm that is filled with water. The plate temperatures are 50 and 20°C. Calculate the heat transfer across the space.
- **7-84** Repeat Problem 7-83 for the plates oriented in a horizontal position with the 50°C surface as the lower plate.
- **7-85** Two vertical plates 1.1 by 1.1 m are separated by a 4.0-cm air space. The two surface temperatures are at 300 and 350 K. The heat transfer in the space can be reduced by decreasing the pressure of the air. Calculate and plot k_e/k and the R value as a function of pressure. To what value must the pressure be reduced to make $k_e/k = 1.0$?
- **7-86** Repeat Problem 7-85 for two horizontal plates with the 350 K surface on the bottom.
- **7-87** An air space in a certain building wall is 10 cm thick and 2 m high. Estimate the free-convection heat transfer through this space for a temperature difference of 17°C.
- **7-88** A vertical enclosed space contains air at 2 atm. The space is 3 m high by 2 m deep and the spacing between the vertical plates is 6 cm. One plate is maintained at 300 K while the other is at 400 K. Calculate the convection heat transfer between the two vertical plates.
- 7-89 Develop an expression for the optimum spacing for vertical plates in air in order to achieve minimum heat transfer, assuming that the heat transfer results from pure conduction at ${\rm Gr}_{\delta} < 2000$. Plot this optimum spacing as a function of temperature difference for air at 1 atm.
- **7-90** Air at atmospheric pressure is contained between two vertical plates maintained at 100°C and 20°C, respectively. The plates are 1.0 m on a side and spaced 8 cm apart. Calculate the convection heat transfer across the air space.
- **7-91** A special section of insulating glass is constructed of two glass plates 30 cm square separated by an air space of 1 cm. Calculate the percent reduction in heat transfer of this arrangement compared to free convection from a vertical plate with a temperature difference of 30°C.
- **7-92** One way to reduce the free-convection heat loss in a horizontal solar collector is to reduce the pressure in the space separating the glass admitting the solar energy and the black absorber below. Assume the bottom surface is at 120°C and the top surface is at 20°C. Calculate the pressures that are necessary to eliminate convection for spacings of 1, 2, 5, and 10 cm.
- **7-93** Air at 20°C and 1 atm is forced upward through a vertical 2.5-cm-diameter tube 30 cm long. Calculate the total heat-transfer rate where the tube wall is maintained at 200°C and the flow velocity is 45 cm/s.
- **7-94** A horizontal tube is maintained at a surface temperature of 55°C and exposed to atmospheric air at 27°C. Heat is supplied to the tube by a suitable electric heater that produces an input of 175 W for each meter of length. Find the expected power input if the surface temperature is raised to 83°C.
- **7-95** A large vertical plate is maintained at a surface temperature of 140°F and exposed to air at 1 atm and 70°F. Estimate the vertical position on the plate where the

372 Problems



- boundary layer becomes turbulent. What is the average q/A for the portion of the plate preceding this location? What is the maximum velocity in the boundary layer at this location?
- **7-96** The horizontal air space over a solar collector has a spacing of 2.5 cm. The lower plate is maintained at 70°C while the upper plate is at 30°C. Calculate the free convection across the space for air at 1 atm. 1f the spacing is reduced to 1.0 cm, by how much is the heat transfer changed?
- **7-97** One concept of a solar collector reduces the pressure of the air gap to a value low enough to eliminate free-convection effects. For the air space in Problem 7-96 determine the pressures to eliminate convection; that is, Gr Pr < 1700.
- **7-98** A 2.5-cm sphere is maintained at a surface temperature of 120°F and exposed to a fluid at 80°F. Compare the heat loss for (a) air and (b) water.
- **7-99** Air at 1 atm is contained between two concentric spheres having diameters of 10 and 8 cm and maintained at temperatures of 300 and 400 K. Calculate the free-convection heat transfer across the air gap.
- 7-100 Some canned goods are to be cooled from room temperature of 300 K by placing them in a refrigerator maintained at 275 K. The cans have diameter and height of 8.0 cm. Calculate the cooling rate. Approximately how long will it take the temperature of the can to drop to 290 K if the contents have the properties of water? Use lumped-capacity analysis.
- **7-101** A 5.0-cm-diameter horizontal disk is maintained at 120°F and submerged in water at 80°F. Calculate the heat lost from the top and bottom of the disk.
- **7-102** A 10-cm-square plate is maintained at 400 K on the bottom side, and exposed to air at 1 atm and 300 K. The plate is inclined at 45° with the vertical. Calculate the heat lost by the bottom surface of the plate.
- **7-103** Calculate the heat transfer for the plate of Problem 7-102 if the heated surface faces upward.
- **7-104** A vertical cylinder 50 cm high is maintained at 400 K and exposed to air at 1 atm and 300 K. What is the minimum diameter for which the vertical-flat-plate relations may be used to calculate the heat transfer? What would the heat transfer be for this diameter?
- **7-105** Derive an expression for the ratio of the heat conducted through an air layer at low density to that conducted for $\lambda = 0$. Plot this ratio versus λ/L for $\alpha = 0.9$ and air properties evaluated at 35°C.
- 7-106 A superinsulating material is to be constructed of polished aluminum sheets separated by a distance of 0.8 mm. The space between the sheets is sealed and evacuated to a pressure of 10⁻⁵ atm. Four sheets are used. The two outer sheets are maintained at 35 and 90°C and have a thickness of 0.75 mm, whereas the inner sheets have a thickness of 0.18 mm. Calculate the conduction and radiation transfer across the layered section per unit area. For this calculation, allow the inner sheets to "float" in the determination of the radiation heat transfer. Evaluate properties at 65°C.
- 7-107 Two large polished plates are separated by a distance of 1.3 mm, and the space between them is evacuated to a pressure of 10^{-5} atm. The surface properties of the plates are $\alpha_1 = 0.87$, $\epsilon_1 = 0.08$, $\alpha_2 = 0.95$, $\epsilon_2 = 0.23$, where α is the accommodation coefficient. The plate temperatures are $T_1 = 70^{\circ}\text{C}$ and $T_2 = 4^{\circ}\text{C}$. Calculate the total heat transfer between the plates by low-density conduction and radiation.
- **7-108** A smooth glass plate is coated with a special coating that is electrically conductive and can produce constant-heat-flux conditions. One of these surfaces, 0.5 m square,





is suspended vertically in room air at 20° C. What heat flux would be experienced and what would be the electric power input to maintain an average surface temperature of 65°C on both sides of the plate? Suppose the plate surface radiates approximately as a blackbody. What amount of heat would be dissipated for the same average surface temperature?

- **7-109** A 20-cm-square vertical plate is heated to a temperature of 30°C and submerged in glycerin at 10°C. Calculate the heat lost from both sides of the plate.
- **7-110** A vertical cylinder 30 cm high and 30 cm in diameter is maintained at a surface temperature of 43.3°C while submerged in water at 10°C. Calculate the heat lost from the total surface area of the cylinder.
- **7-111** A 1.0-cm-diameter horizontal cylinder is maintained at a constant surface temperature of 400 K and exposed to oxygen at 300 K and 1.5 atm. The length of the cylinder is 125 cm. Calculate the heat lost by the cylinder.
- 7-112 Air is contained between two vertical plates spaced 2 cm apart, with the air space evacuated so that the mean free path is equal to the plate spacing. One plate is at $400\,\mathrm{K}$ with $\epsilon = 0.1$ while the other plate is at $300\,\mathrm{K}$ with $\epsilon = 0.15$. The accommodation coefficients for the surfaces are 0.9. Calculate the heat transfer between the two plates.
- **7-113** A 40-cm-diameter sphere is maintained at 400 K and exposed to room air at 20°C. Calculate the free convection heat loss from the sphere. If the surface has $\epsilon = 0.9$, also calculate the radiation heat lost from the sphere.
- **7-114** Two 20-cm-square plates are maintained at 350 and 400 K and separated by a distance of 2 cm. The space between the plates is filled with helium at 2 atm. Calculate the heat transfer through the gap space.
- **7-115** A 30-cm-square horizontal plate is exposed to air at 1 atm and 25°C. The plate surface is maintained at 125°C on both sides. Calculate the free convection loss from the plate.
- 7-116 A horizontal 1-mm-diameter stainless-steel wire having $k = 16 \text{ W/m} \cdot ^{\circ}\text{C}$ and a resistivity of 70 $\mu\Omega$ cm is exposed to air at 1 atm and 20°C. The wire length is 1 m. What is the maximum temperature that will occur in the wire and the voltage that must be impressed on it to produce a surface temperature of 134°C?
- **7-117** A vertical cylindrical surface has a diameter of 10.5 cm, a height of 30 cm, and is exposed to air at 1 atm and 15°C. The cylindrical surface is maintained at 100°C. Calculate the free convection heat loss from the cylindrical surface. State your assumptions.
- **7-118** A wire having a diameter of 0.025 mm is placed in a horizontal position in room air at 1 atm and 300 K. A voltage is impressed on the wire, producing a surface temperature of 865 K. The surface emissivity of the wire is 0.9. Calculate the heat loss from the wire per unit length by both free convection and radiation.
- **7-119** A flat surface having the shape of an equilateral triangle, 20 cm on a side, is maintained at 400 K and exposed to air at 1 atm and 300 K. Calculate the heat lost from the top surface of the triangle.
- **7-120** A horizontal disk having a diameter of 10 cm is maintained at 49°C and submerged in water at 1 atm and 10°C. Calculate the free convection heat loss from the top surface of the disk.

Design-Oriented Problems

7-121 A free-convection heater is to be designed that will dissipate 10,000 kJ/h to room air at 300 K. The heater surface temperature must not exceed 350 K. Consider four

374 Problems



- alternatives: (a) a group of vertical surfaces, (b) a single vertical surface, (c) a single horizontal surface, and (d) a group of horizontal cylindrical surfaces. Examine these alternatives and suggest a design.
- **7-122** A special double-pane insulating window glass is to be constructed of two glass plates separated by an air gap. The plates are square, 60 by 60 cm, and are designed to be used with temperatures of -10 and $+20^{\circ}$ C on the respective plates. Assuming the air in the gap is at 1 atm, calculate and plot the free convection across the gap as a function of gap spacing for a vertical window. What conclusions can you draw from this plot from a design standpoint?
- **7-123** A standing rib roast is cooked for a holiday dinner and is removed from the oven when the temperature reaches 120°C. The roast cools by combined free convection and radiation in a room at 300 K. Using whatever reference material is necessary, estimate the time required for the temperature of the roast to reach 50°C. Be sure to state all assumptions.
- **7-124** Repeat Problem 7-122 for a horizontal window with the hot surface on the lower side.
- **7-125** Energy-conservation advocates claim that storm windows can substantially reduce energy losses (or gains). Consider a vertical 1.0-m-square window covered by a storm window with an air gap of 2.5 cm. The inside window is at 15° C and the outside storm window is at -10° C. Calculate the *R* value for the gap. What would the *R* value be for the same thickness of fiberglass blanket?
- 7-126 An evacuated thermal insulation is to be designed that will incorporate multiple layers of reflective sheets ($\epsilon = 0.04$) separated by air gap spaces that are partially evacuated and have spacing δ sufficiently small that $k_e/k = 1.0$. The insulation is to be designed to operate over a temperature differential from 0°C to 200°C. Investigate the possibilities of using 1, 2, 3, or 4 gap spaces and comment on the influence of different factors on the design, such as gap-space size and the evacuation pressure necessary to produce $k_e/k = 1.0$.
- 7-127 Aunt Maude frequently complains of a "draft" while sitting next to a window in her New York apartment in the winter, and she also says her feet get cold. She remarks that the window seems to leak cold air in the winter but not hot air in the summer. (She has air-conditioning, so her windows are closed in the summer.) Using appropriate assumptions, analyze and explain the "draft" problem and make some quantitative estimates of what the draft may be. How does the analysis account for her feet being cold?
- **7-128** A circular air-conditioning duct carries cool air at 5°C and is constructed of 1 percent carbon steel with a thickness of 0.2 mm and an outside diameter of 18 cm. The duct is in a horizontal position and gains heat from room air at 20°C. If the average air velocity in the duct is 7.5 m/s, estimate the air temperature rise in a duct run of 30 m. Be sure to state your assumptions in arriving at an answer.
- 7-129 An experiment is to be designed to measure free convection heat-transfer coefficients from spheres by preheating aluminum spheres of various diameters to an initial temperature and then measuring the temperature response as each sphere cools in room air. Because of the low value of the Biot number (see Chapter 4) the sphere may be assumed to behave as a lumped capacity. The sphere is also blackened so that the radiation loss from the outer surface will be given by $q_{\rm rad} = \sigma A_{\rm surf} (T^4 T_{\rm surr}^4)$, where the temperatures are in degrees Kelvin. From information in this chapter, anticipate the cooling curve behavior for 5-mm-, 25-mm-, and 50-mm-diameter aluminum spheres cooling from 230°C in room air at 20°C. How often would you





advise reading the temperatures of the spheres and room? What range of Rayleigh numbers would you expect to observe in these experiments? Can you suggest a way to correlate the data in terms of the significant dimensionless groups?

7-130 In a television weather report a "wind chill factor" is frequently stated. The actual factor is based on empirical data. You are asked to come up with an expression for wind chill based on the information presented in Chapters 6 and 7. In obtaining this relation you may assume that (1) a man can be approximated as a vertical cylinder 30 cm in diameter and 1.8 m tall, (2) wind chill expresses the equivalent air temperature the cylinder would experience in free convection when losing heat by forced convection to air at the ambient temperature and velocity u_{∞} , (3) forced convection heat loss from the cylinder can be obtained from Equation (6-17) with the appropriate values of C and n, and (4) free convection from the vertical cylinder can be obtained from the simplified expressions of Table 7-2. Based on these assumptions, devise relationship(s) to predict the wind chill for ambient temperatures between -12 and $+10^{\circ}$ C and wind velocities between 5 and 40 mi/h (1 mi/h = 0.447 m/s). Other assumptions must be made in addition to the ones stated. Be sure to clearly note your assumptions in arriving at the relation(s) for wind chill. If convenient, check other sources of information to verify your results. If you are currently experiencing winter weather, compare your results with a television weather report.

REFERENCES

- 1. Eckert, E. R. G., and E. Soehngen. "Interferometric Studies on the Stability and Transition to Turbulence of a Free Convection Boundary Layer," *Proc. Gen. Discuss. Heat Transfer ASMEIME, London,* 1951.
- **2.** Eckert, E. R. G., and E. Soehngen. "Studies on Heat Transfer in Laminar Free Convection with the Zehnder-Mach Interferometer," *USAF Tech. Rep.* 5747, December 1948.
- **3.** Holman, J. P., H. E. Gartrell, and E. E. Soehngen. "An Interferometric Method of Studying Boundary Layer Oscillations," *J. Heat Transfer*, ser. C, vol. 80, August 1960.
- 4. McAdams, W. H. Heat Transmission, 3d ed., New York: McGraw-Hill, 1954.
- **5.** Yuge, T. "Experiments on Heat Transfer from Spheres Including Combined Natural and Forced Convection," *J. Heat Transfer*, ser. C, vol. 82, p. 214, 1960.
- 6. Jakob, M. "Free Convection through Enclosed Gas Layers," Trans. ASME, vol. 68, p. 189, 1946.
- 7. Jakob, M. Heat Transfer, vol. 1, New York: John Wiley, 1949.
- 8. Globe, S., and D. Dropkin. J. Heat Transfer, February 1959, pp. 24–28.
- **9.** Evans, L. B., and N. E. Stefany. "An Experimental Study of Transient Heat Transfer to Liquids in Cylindrical Enclosures," *AIChE Pap. 4, Heat Transfer Conf Los Angeles*, August 1965.
- **10.** Metais, B., and E. R. G. Eckert. "Forced, Mixed, and Free Convection Regimes," *J. Heat Transfer*, ser. C, vol. 86, p. 295, 1964.
- 11. Bishop, E. N., L. R. Mack, and J. A. Scanlan. "Heat Transfer by Natural Convection between Concentric Spheres," *Int. J. Heat Mass Transfer*, vol. 9, p. 649, 1966.
- **12.** Dropkin, D., and E. Somerscales. "Heat Transfer by Natural Convection in Liquids Confined by Two Parallel Plates Which Are Inclined at Various Angles with Respect to the Horizontal," *J. Heat Transfer*, vol. 87, p. 71, 1965.
- **13.** Gebhart, B., Y. Jaluria, R. L. Mahajan, and B. Sammakia. *Buoyancy Induced Flows and Transport*. New York: Hemisphere Publishing Corp., 1988.
- **14.** Gebhart, B. "Natural Convection Flow, Instability, and Transition," *ASME Pap.* 69-HT-29, August 1969.





References

- **15.** Mollendorf, J. C., and B. Gebhart. "An Experimental Study of Vigorous Transient Natural Convection," *ASME Pap.* 70-HT-2, May 1970.
- Bayley, F. J. "An Analysis of Turbulent Free Convection Heat Transfer," Proc. Inst. Mech. Eng., vol. 169, no. 20, p. 361, 1955.
- **17.** Brown, C. K., and W. H. Gauvin. "Combined Free and Forced Convection, I, II," *Can. J. Chem. Eng.*, vol. 43, no. 6, pp. 306, 313, 1965.
- MacGregor, R. K., and A. P. Emery. "Free Convection through Vertical Plane Layers: Moderate and High Prandtl Number Fluids," *J. Heat Transfer*, vol. 91, p. 391, 1969.
- **19.** Newell, M. E., and F. W. Schmidt. "Heat Transfer by Laminar Natural Convection within Rectangular Enclosures," *J. Heat Transfer*, vol. 92, pp. 159–168, 1970.
- Husar, R. B., and E. M. Sparrow. "Patterns of Free Convection Flow Adjacent to Horizontal Heated Surfaces," Int. J. Heat Mass Trans., vol. 11, p. 1206, 1968.
- **21.** Habne, E. W. P. "Heat Transfer and Natural Convection Patterns on a Horizontal Circular Plate," *Int. J. Heat Mass Transfer*, vol. 12, p. 651, 1969.
- 22. Warner, C. Y., and V. S. Arpaci. "An Experimental Investigation of Turbulent Natural Convection in Air at Low Pressure along a Vertical Heated Flat Plate," *Int. J. Heat Mass Transfer*, vol. 11, p. 397, 1968.
- 23. Gunness, R. C., Jr., and B. Gebhart. "Stability of Transient Convection," *Phys. Fluids*, vol. 12, p. 1968, 1969.
- Rotern, Z., and L. Claassen. "Natural Convection above Unconfined Horizontal Surfaces," J. Fluid Mech., vol. 39, pt. 1, p. 173, 1969.
- **25.** Vliet, G. C. "Natural Convection Local Heat Transfer on Constant Heat Flux Inclined Surfaces," *J. Heat Transfer*, vol. 91, p. 511, 1969.
- **26.** Vliet, G. C., and C. K. Lin. "An Experimental Study of Turbulent Natural Convection Boundary Layers," *J. Heat Transfer*, vol. 91, p. 517, 1969.
- 27. Ostrach, S. "An Analysis of Laminar-Free-Convection Flow and Heat Transfer about a Flat Plate Parallel to the Direction of the Generating Body Force," *NACA Tech. Rep.* 1111, 1953.
- 28. Cheesewright, R. "Turbulent Natural Convection from a Vertical Plane Surface," *J. Heat Transfer*, vol. 90, p. 1, February 1968.
- **29.** Flack, R. D., and C. L. Witt. "Velocity Measurements in Two Natural Convection Air Flows Using a Laser Velocimeter," *J. Heat Transfer*, vol. 101, p. 256, 1979.
- Eckert, E. R. G., and T. W. Jackson. "Analysis of Turbulent Free Convection Boundary Layer on a Flat Plate," NACA Rep. 1015, 1951.
- King, W. J. "The Basic Laws and Data of Heat Transmission," Mech. Eng., vol. 54, p. 347, 1932.
- **32.** Sparrow, E. M., and J. L. Gregg. "Laminar Free Convection from a Vertical Flat Plate," *Trans. ASME*, vol. 78, p. 435, 1956.
- **33.** Benard, H. "Les Tourbillons cellulaires dans une nappe liquide transportant de la chaleur par convection en régime permanent," *Ann. Chim. Phys.*, vol. 23, pp. 62–144, 1901.
- Progress in Heat and Mass Transfer, vol. 2, Eckert Presentation Volume. New York: Pergamon Press, 1969.
- 35. Gebhart, B., T. Audunson, and L. Pera. Fourth Int. Heat Transfer Conf., Paris, August 1970.
- **36.** Sanders, C. J., and J. P. Holman. "Franz Grashof and the Grashof Number," *Int. J. Heat Mass Transfer*, vol. 15, p. 562, 1972.
- **37.** Clifton, J. V., and A. J. Chapman. "Natural Convection on a Finite-Size Horizontal Plate," *Int. J. Heat Mass Transfer*, vol. 12, p. 1573, 1969.
- **38.** Emery, A. F., H. W. Chi, and J. D. Dale. "Free Convection through Vertical Plane Layers of Non-Newtonian Power Law Fluids," *ASME Pap.* 70-WA/HT-1.
- Vliet, G. C. "Natural Convection Local Heat Transfer on Constant Heat Flux Inclined Surfaces," Trans. ASME, vol. 91C, p. 511, 1969.





- **40.** Bergles, A. E., and R. R. Simonds. "Combined Forced and Free Convection for Laminar Flow in Horizontal Tubes with Uniform Heat Flux," *Int. J. Heat Mass Transfer*, vol. 14, p. 1989, 1971.
- **41.** Aihara, T., Y. Yamada, and S. Endo. "Free Convection along the Downward-facing Surface of a Heated Horizontal Plate," *Int. J. Heat Mass Transfer*, vol. 15, p. 2535, 1972.
- **42.** Saunders, O. A., M. Fishenden, and H. D. Mansion. "Some Measurement of Convection by an Optical Method," *Engineering*, p. 483, May 1935.
- **43.** Weber, N., R. E. Rowe, E. H. Bishop, and J. A. Scanlan. "Heat Transfer by Natural Convection between Vertically Eccentric Spheres," *ASME Pap.* 72-WA/HT-2.
- **44.** Fujii, T., and H. Imura. "Natural Convection Heat Transfer from a Plate with Arbitrary Inclination," *Int. J. Heat Mass Transfer*, vol. 15, p. 755, 1972.
- **45.** Pera, L., and B. Gebhart. "Natural Convection Boundary Layer Flow over Horizontal and Slightly Inclined Surfaces," *Int. J. Heat Mass Transfer*, vol. 16, p. 1131, 1973.
- **46.** Hyman, S. C., C. F. Bonilla, and S. W. Ehrlich. "Heat Transfer to Liquid Metals from Horizontal Cylinders," *AiChE Symp. Heat Transfer, Atlantic City*, 1953, p. 21.
- **47.** Fand, R. M., and K. K. Keswani. "Combined Natural and Forced Convection Heat Transfer from Horizontal Cylinders to Water," *Int. J. Heat Mass Transfer*, vol. 16, p. 175, 1973.
- **48.** Dale, J. D., and A. F. Emery. "The Free Convection of Heat from a Vertical Plate to Several Non-Newtonian Pseudoplastic Fluids," *ASME Pap.* 71-HT-S.
- **49.** Fujii, T., O. Miyatake, M. Fujii, H. Tanaka, and K. Murakami. "Natural Convective Heat Transfer from a Vertical Isothermal Surface to a Non-Newtonian Sutterby Fluid," *Int. J. Heat Mass Transfer*, vol. 16, p. 2177, 1973.
- **50.** Soehngen, E. E. "Experimental Studies on Heat Transfer at Very High Prandtl Numbers," *Prog. Heat Mass Transfer*, vol. 2, p. 125, 1969.
- **51.** Vliet, G. C., and D. C. Ross. "Turbulent Natural Convection on Upward and Downward Facing Inclined Constant Heat Flux Surfaces," *ASME Pap.* 74-WA/HT-32.
- **52.** Llyod, J. R., and W. R. Moran. "Natural Convection Adjacent to Horizontal Surface of Various Planforms," *ASME Pap.* 74-WA/HT-66.
- **53.** Goldstein, R. J., E. M. Sparrow, and D.C. Jones. "Natural Convection Mass Transfer Adjacent to Horizontal Plates," *Int. J. Heat Mass Transfer*, vol. 16, p. 1025, 1973.
- **54.** Holman, J. P., and J. H. Boggs. "Heat Transfer to Freon 12 near the Critical State in a Natural Circulation Loop," *J. Heat Transfer*, vol. 80, p. 221, 1960.
- 55. Mull, W., and H. Reiher. "Der Wärmeschutz von Luftschichten," *Beih. Gesund. Ing.*, ser. 1, no. 28, 1930.
- **56.** Krasshold, H. "Wärmeabgabe von zylindrischen Flussigkeitsschichten bei natürlichen Konvektion," *Forsch. Geb. Ingenieurwes*, vol. 2, p. 165, 1931.
- 57. Beckmann, W. "Die Wärmeübertragung in zylindrischen Gasschichten bei natürlicher Konvektion," Forsch. Geb. Ingenieurwes, vol. 2, p. 186, 1931.
- **58.** Schmidt, E. "Free Convection in Horizontal Fluid Spaces Heated from Below." *Proc. Int. Heat Transfer Conf., Boulder, Col., ASME,* 1961.
- **59.** Graff, J. G. A., and E. F. M. Van der Held. "The Relation between the Heat Transfer and Convection Phenomena in Enclosed Plain Air Players," *Appl. Sci. Res.*, ser. A, vol. 3, p. 393, 1952.
- **60.** Liu, C. Y., W. K. Mueller, and F. Landis. "Natural Convection Heat Transfer in Long Horizontal Cylindrical Annuli," *Int. Dev. Heat Transfer*, pt. 5, pap. 117, p. 976, 1961.
- Emery, A., and N. C. Chu. "Heat Transfer across Vertical Layers," J. Heat Transfer, vol. 87, p. 110, 1965.
- **62.** O'Toole, J., and P. L. Silveston. "Correlation of Convective Heat Transfer in Confined Horizontal Layers," *Chem. Eng. Prog. Symp.*, vol. 57, no. 32, p. 81, 1961.
- **63.** Goldstein, R. J., and T. Y. Chu. "Thermal Convection in a Horizontal Layer of Air," *Prog. Heat Mass Transfer*, vol. 2, p. 55, 1969.





References

- **64.** Singh, S. N., R. C. Birkebak, and R. M. Drake. "Laminar Free Convection Heat Transfer from Downward-facing Horizontal Surfaces of Finite Dimensions," *Prog. Heat Mass Transfer*, vol. 2, p. 87, 1969.
- **65.** McDonald, J. S., and T. J. Connally. "Investigation of Natural Convection Heat Transfer in Liquid Sodium," *Nucl Sci. Eng.*, vol. 8, p. 369, 1960.
- 66. Hollands, K. G. T., G. D. Raithby, and L. Konicek. "Correlation Equations for Free Convection Heat Transfer in Horizontal Layers of Air and Water," *Int. J. Heat Mass Transfer*, vol. 18, p. 879, 1975.
- 67. Hollands, K. G. T., T. E. Unny, and G. D. Raithby. "Free Convective Heat Transfer across Inclined Air Layers," *ASME Pap.* 75-HT-55, August 1975.
- Depew, C. A., J. L. Franklin, and C. H. Ito. "Combined Free and Forced Convection in Horizontal, Uniformly Heated Tubes," ASME Pap. 75-HT-19, August 1975.
- **69.** Raithby, G. D., and K. G. T. Hollands. "A General Method of Obtaining Approximate Solutions to Laminar and Turbulent Free Convection Problems," *Advances in Heat Transfer*, New York: Academic Press, 1974.
- 70. Churchill, S. W., and H. H. S. Chu. "Correlating Equations for Laminar and Turbulent Free Convection from a Horizontal Cylinder," *Int. J. Heat Mass Transfer*, vol. 18, p. 1049, 1975.
- **71.** Churchill, S. W., and H. H. S. Chu. "Correlating Equations for Laminar and Turbulent Free Convection from a Vertical Plate," *Int. J. Heat Mass Transfer*, vol. 18, p. 1323, 1975.
- **72.** Churchill, S. W. "A Comprehensive Correlating Equation for Laminar, Assisting, Forced and Free Convection," *AiChE J.*, vol. 23, no. 1, p. 10, 1977.
- **73.** Al-Arabi, M., and Y. K. Salman. "Laminar Natural Convection Heat Transfer from an Inclined Cylinder," *Int. J. Heat Mass Transfer*, vol. 23, pp. 45–51, 1980.
- 74. Holman, J. P. Heat Transfer, 4th ed. New York: McGraw-Hill, 1976.
- Hatfield, D. W., and D. K. Edwards. "Edge and Aspect Ratio Effects on Natural Convection from the Horizontal Heated Plate Facing Downwards," *Int. J. Heat Mass Transfer*, vol. 24, p. 1019, 1981.
- **76.** Morgan, V. T. *The Overall Convective Heat Transfer from Smooth Circular Cylinders, Advances in Heat Transfer* (T. F. Irvine and J. P. Hartnett, eds.), vol.11, New York: Academic Press, 1975.
- 77. Sparrow, E. M., and M. A. Ansari. "A Refutation of King's Rule for Multi-Dimensional External Natural Convection," *Int. J. Heat Mass Transfer*, vol. 26, p. 1357, 1983.
- **78.** Lienhard, J. H. "On the Commonality of Equations for Natural Convection from Immersed Bodies," *Int. J. Heat Mass Transfer*, vol. 16, p. 2121, 1973.
- Amato, W. S., and C. L. Tien. "Free Convection Heat Transfer from Isothermal Spheres in Water," Int. J. Heat Mass Transfer, vol. 15, p. 327, 1972.
- **80.** Warrington, R. O., and R. E. Powe. "The Transfer of Heat by Natural Convection Between Bodies and Their Enclosures," *Int. J. Heat Mass Transfer*, vol. 28, p. 319, 1985.
- **81.** Sparrow, E. M., and A. J. Stretton. "Natural Convection from Bodies of Unity Aspect Ratio," *Int. J. Heat Mass Transfer*, vol. 28, p. 741, 1985.
- **82.** El Sherbing, S. M., G. D. Raithby, and K. G. T. Hollands. "Heat Transfer across Vertical and Inclined Air Layers," *J. Heat Transfer*, vol. 104C, p. 96, 1982.
- **83.** Churchill, S. W. "Free Convection Around Immersed Bodies," p. 2.5.7–24, in G. F. Hewitt (ed.), *Heat Exchanger Design Handbook*, Washington, D.C.: Hemisphere Publishing Corp., 1983.
- **84.** Minkowycz, W. J., and E. M. Sparrow. "Local Nonsimilar Solutions for Natural Convection on a Vertical Cylinder," *J. Heat Transfer*, vol. 96, p. 178, 1974.