

Traffic Engineering Studies

Prof. Dr. Zainab Al –Khaissi

Assist Prof. Dr. Siham I. Salih



Traffic studies may be grouped into three main categories:

- **(1) Inventories**
- **(2) administrative studies**
- **(3) Dynamic studies.**



- **Inventories** : provide a list or graphic display of existing information, such as:
 - street widths,
 - parking spaces,
 - Transit routes
 - traffic regulations.
- Some inventories—for example, available parking spaces and traffic regulations—change frequently and therefore require periodic updating; others, such as street widths, do not



- **Administrative studies :**
- Use existing engineering records, available in government agencies and departments. This information is used to prepare an inventory of the relevant data.
- Inventories may be recorded in files but are usually recorded in automated data processing (ADP) systems

Administrative studies include the results of surveys, which may involve:

- ☐ field measurements and/or
- ☐ aerial photography.



- **(2) Dynamic traffic studies:** involve
- **the collection of data** under **operational conditions** and include:
 - ❑ Studies of speed.
 - ❑ Studies of traffic volume,
 - ❑ Studies of travel time and delay,
 - ❑ Studies of parking and crashes.



Since dynamic studies are carried out by the traffic engineer to evaluate current conditions and develop solutions :

- **Traffic Volume Studies**

Traffic volume studies are conducted to collect data on the number of vehicles and/or pedestrians that pass a point on a highway facility during a specified time period. This time period varies from as little as 15 minutes to as much as a year depending on the anticipated use of the data. The data collected also may be put into subclasses which may include directional movement, occupancy rates, vehicle classification, and pedestrian age.




Why are Volume Studies Needed?

Transportation planning/forecasts

- ❑ Assessing operations
- ❑ Impact analysis
- ❑ Determining need for traffic control • • •, etc.

Traffic counts provide the primary measure of demand.






Volume: The number of vehicles (or persons) passing a point during a specified time period which is usually one hour but need not be.

Rate of Flow: The rate at which vehicles (or persons) pass a point during a specified time period less than an hour, expressed as an equivalent hourly rate.


Demand: The number of vehicles (or persons) that desire to travel past a point during a specified time period (usually one hour). .




Capacity: The maximum rate at which vehicles can traverse a point or short segment during a specified time period.



Demand Exceeding Capacity



Volume Pattern



Volume Patterns and Characteristics


Traffic demand varies!

Choosing design hour may be complex

Very important to understand volume variation patterns



Bottleneck Effects




Bottleneck Effects

①	②	③	④	⑤
3200 vph	3200 vph	3400 vph	3000 vph	3000 vph

(b) Segment Capacities




Bottleneck Effects



(c) Observed Volumes




Observed Hourly Traffic Patterns



(a) Typical Variations for Rural Routes




Observed Daily Variations



(b) Daily Variation in Volumes at Four Urban Locations



Volume Patterns and Characteristic




- Main rural route I-35, Southern Minnesota, AADT 10,823, 4 lanes, 1980.
- - - Recreational access route MN 169, North-Central Lake Region, AADT 3,863, 2 lanes, 1981.
- Suburban freeway, four freeways in Minneapolis-St. Paul, AADTs 75,000-130,000, 6-8 lanes, 1982.
- . - . Average day.


Source: Minnesota Department of Transportation.




Monthly Variation



Peak Hour Volume



Within Peak Hour



Volume Studies

Manual counts

- ☐ Useful when data is needed quickly, duration of study is short, or scope is limited
- ☐ Useful when more detail is needed such as:
 - o Vehicle occupancy
 - o Pedestrians
 - o Turning movements
 - o Vehicle classifications




Automatic counts


- ☐ Useful when complex classifications not necessary.
- ☐ Useful when data is needed over an extended period of time.



Intersection Traffic Volume Count



Intersection Traffic Volume Count



Limited Network Volume Studies

- ❑ Sampling techniques are used along with statistical manipulation to develop an hourly volume map for the network.
- ❑ Requires identification of locations with similar demand patterns over time.
- ❑ Uses control and coverage counts.
- ❑ Control count - maintained throughout study period; selected locations are measured to identify demand variation patterns.



Limited Network Volume Studies

- ❑ Coverage count – taken at all locations in study area for a portion of study period (samples).
- ❑ Midblock counts

Control Count

- ❖ One control for every 10- 20 coverage locations.
- ❖ Different control for each class of facility.
- ❖ Different control for significantly different land-use type.
- ❖ Used to establish volume patterns




Coverage Count

- ☐ These are sample locations which will be expanded with control information.
- ☐ All network links should be counted at least once during study period.



Control Count



Network wide Studies

Control-Count Data Location A		Coverage-Count Data		
Time (PM)	Count (vehs)	Location	Time (PM)	Count (vehs)
12-1	825	1	12-1	840
1-2	811	2	1-2	625
2-3	912	3	2-3	600
3-4	975	4	4-5	390
4-5	1,056	5	5-6	1,215
5-6	1,153	6	6-7	1,440
6-7	938			
7-8	397			

(a) Data from a One-Day Study



Network wide Studies

Time (PM)	Count (vehs)	Proportion of 8-Hour Total
12-1	825	$825/7,067 = 0.117$
1-2	811	$811/7,067 = 0.115$
2-3	912	$912/7,067 = 0.129$
3-4	975	$975/7,067 = 0.138$
4-5	1,056	$1,056/7,067 = 0.149$
5-6	1,153	$1,153/7,067 = 0.163$
6-7	938	$938/7,067 = 0.133$
7-8	397	$397/7,067 = 0.056$
Total	7,067	1.000



Network wide Studies

(b) Computation of Hourly Volume Proportions From Control-Count Data

Location	Time (PM)	Count (vehs)	Estimated 8-Hr Volume (vehs)	Estimated Peak Hour Volume (vehs)
1	12-1	840	$840/0.117 = 7,179$	$\times 0.163 = 1,170$
2	1-2	625	$625/0.115 = 5,435$	$\times 0.163 = 886$
3	2-3	600	$600/0.129 = 4,651$	$\times 0.163 = 758$
4	4-5	390	$390/0.149 = 2,617$	$\times 0.163 = 427$
5	5-6	1,215	$1,215/0.163 = 7,454$	$\times 0.163 = 1,215$
6	6-7	1,440	$1,440/0.133 = 10,827$	$\times 0.163 = 1,765$

(c) Expansion of Hourly Counts




Daily Variation Factor

Day	Yearly Average Volume for Day (vehs/day)	Daily Adjustment Factor (DF)
Monday	1820	$1430/1820 = 0.79$
Tuesday	1588	$1430/1588 = 0.90$
Wednesday	1406	$1430/1406 = 1.02$
Thursday	1300	$1430/1300 = 1.10$
Friday	1289	$1430/1289 = 1.11$
Saturday	1275	$1430/1275 = 1.12$
Sunday	1332	$1430/1332 = 1.07$
Total	10,010	
Estimated AADT	1,430	



Weekly Variation Factor



Daily and Monthly Adjustment Factors

Daily Factors (DF)		Monthly Factors (MF)			
Day	Factor	Month	Factor	Month	Factor
Monday	1.072	January	1.215	July	0.913
Tuesday	1.121	February	1.191	August	0.882
Wednesday	1.108	March	1.100	September	0.884
Thursday	1.098	April	0.992	October	0.931
Friday	1.015	May	0.949	November	1.026
Saturday	0.899	June	0.918	December	1.114
Sunday	0.789				



Network wide (AADT)

$$\text{AADT} = V_{24ij} * D_{fi} * M_{Fj}$$

AADT : Average annual daily traffic j

V_{24ij} : 24-hour volume for day i, in month

D_{fi} : Daily adjustment factor for day i

M_{Fj} : Monthly adjustment factor for month j



Vehicle Miles Travelled

$$\text{VMT}_{365} = \text{AADT} * L * 365$$

- Annual vehicle miles travelled over the segment.
- AADT for the segment (veh/day).
- Length of the segment.



Manual Counts



Manual Counts


Figure 1 – Manual Count Checklist

Project: _____
Count Location: _____
Date: _____
Time of Count: _____

- _____ 1. Check data collection equipment for proper operation and calibration
- _____ 2. Label the field equipment as needed
- _____ 3. Bring necessary accessory equipment (Batteries, flashlight, etc)
- _____ 4. Stopwatch
- _____ 5. Bring data collection forms and fill in as much data as possible before leaving the office.
- _____ 6. Extra pens and paper for taking notes
- _____ 7. Clipboard or writing surface
- _____ 8. Business cards of the engineer to contact and be prepared to answer the question "What are you doing here?"
- _____ 9. A map to the site
- _____ 10. Weather condition equipment (Sunscreen, umbrella, jacket or warm coat)
- _____ 11. Safety equipment (Flags, Signs, safety vests, or other reflective materials)



Intersection Summary Sheet



[illegible]

Field Considerations

- ❖ Everyone should be familiar with count procedure/labels/equipment
- ❖ Must have enough members in field to adequately record, provide relief, and to address safety concerns
- ❖ Be prepared!!!
- ❖ Observer locations (manual studies).
- ❖ Count location (automatic studies).
- ❖ Be sure to secure equipment for automatic counts.
- ❖ Install equipment during very low volume time periods.
- ❖ Safety vests!



Count Periods

- ❖ 2 hours, peak period
- ❖ 4 hours, am/pm peak period
- ❖ 6 hours, am/midday/pm peak periods
- ❖ 12 hours daytime (7am-7pm)
- ❖ 24 hours, week, month, etc. (automatic)

Typical Peak Flow Traffic Hours

Land Use	Typical Peak Hours
Residential	7:00-9:00 am weekday 4:00-6:00 pm weekday
Regional Shopping center	5:00-6:00 pm weekday 2:30-3:30 pm Saturday 12:30-1:30 pm Saturday
Office	7:00-9:00 am weekday 4:00-6:00 pm weekday
Industrial	Varies
Recreational	Varies
Hospital	Varies based on shift changes
School	Varies based on school release times

Intersection Studies

- Typical 4-leg intersection has 12 separate movements
- Vehicles usually counted as they depart the intersection.
- Must record queue size
$$V_{ai} = V_{di} + N_{qi} - N_{qi-1}$$

V_{ai} = arrival volume in period i , vehs
 V_{di} = departure volume in period i , vehs.
 N_{qi} = number of queued vehs at end of period i , vehs.
 N_{qi-1} = number of queued vehs at end of period $i - 1$, vehs.

Time Period	Total Departure Count (veh)	Queue Length (veh)	Arrival Volume (veh)
4:00-4:15 pm	50	0	50
4:15-4:30	55	0	55
4:30-4:45	62	5	$62 + 5 = 67$
4:45-5:00	65	10	$65 + 10 - 5 = 70$
5:00-5:15	60	12	$60 + 12 - 10 = 62$
5:15-5:30	60	5	$60 + 5 - 12 = 53$
5:30-5:45	62	0	$62 - 5 = 57$
5:45-6:00	55	0	55
	Total = 469		Total = 469

Specialized Counting Studies

Origin and destination counts

- o Weaving areas.
- o Freeway studies.
- o Major activity centers.

Cordon counts

- o Estimate vehicle and person accumulation within the cordon.
- o Used to supplement O-D studies or for trend analysis.

Screen-line

- o Record travel from one area to another.
- o Used to adjust results of O-D studies.

For specialized counts, must have more than just count data.

Types of Volume Studies

- ☐ Intersection counts (duration depends on the purpose, 15-minute intervals or shorter, turning volumes)
- ☐ Pedestrian counts (duration depends on the purpose, 5-minute intervals or longer).
- ☐ Cordon counts (one weekday + travelers' survey).

- ❑ Screen line counts (hourly counts for a weekday).
- ❑ Area wide counts.
 - Control counts (hourly counts with permanent stations).
 - Coverage counts (hourly counts for one or two days).

❑ **Origin-Destination Counts**

- License plate studies
- Recording license plates at entry and exit.


❑ **Postcard studies**

- Handing out color coded post cards at entry points and collecting them at exit.

❑ **Interview studies**

- Stopping vehicles and interviewing them about trip details..

O-D Counts Example



Destination Station	Origin Station				T_j	V_j	F_j
	1	2	3	4			
1	50	8	20	17	95	250	2.63
2	10	65	21	10	106	310	2.92
3	15	12	38	15	80	200	2.50
4	13	14	18	42	87	375	4.31
T_i	88	99	97	84	368		
V_i	210	200	325	400		1135	
F_i	2.39	2.02	3.35	4.76			

(a) Field Data and Factors for Iteration 0

$$T_{ijN} = T_{ijN-1} \left(\frac{F_i + F_j}{2} \right)$$

F_i : Adjustment factor for origin i

F_j : Adjustment factor for origin j

T_{ijN} : Number of trips from station i to station j after Nth iteration

T_i : Sum of matched trips from station

T_j : Sum of matched trips from station j

V_i : Observed total volume at Station i

V_j : Observed total volume at Station j

Destination Station	Origin Station				T_j	V_j	F_j
	1	2	3	4			
1	125	19	60	63	267	250	0.94
2	27	161	66	38	292	310	1.06
3	37	27	111	54	229	200	0.87
4	44	44	69	191	347	375	1.08
T_i	232	251	306	346	1135		
V_i	210	200	325	400		1135	
F_i	0.90	0.80	1.06	1.16			

(b) Initial Expansion of O-D Matrix (Iteration 0)


Destination Station	Origin Station				T_j	V_j	F_j
	1	2	3	4			
1	116	16	60	66	257	250	0.97
2	26	150	70	43	288	310	1.04
3	33	23	108	55	218	200	0.92
4	43	42	74	213	372	375	1.01
T_i	217	230	311	376	1135		
V_i	210	200	325	400		1135	
F_i	0.97	0.87	1.04	1.06			

(c) First Iteration of O-D Matrix


Destination Station	Origin Station				T_j	V_j	F_j
	1	2	3	4			
1	112	15	60	67	254	250	0.98
2	27	145	74	46	292	310	1.06
3	31	20	105	55	211	200	0.95
4	43	39	76	221	378	375	0.99
T_i	212	220	316	388	1135		
V_i	210	200	325	400		1135	
F_i	0.99	0.91	1.03	1.03			

(d) Second Iteration of O-D Matrix

Cordon Counts



Screen-Line Counts



Next Lecture. Spot Speed Studies

Thank you

